

HRC⁷⁰

**High-temperature, modulating
HRC⁷⁰ Heat Pump and Pilot
Energy Efficient**



Installation and operating instructions

HRC⁷⁰ Pilot



HRC⁷⁰ 17 single phase
Ref.151201

HRC⁷⁰ 17 three phase
Ref.151211

HRC⁷⁰ 20 three phase
Ref.151271

HRC⁷⁰ 25 three phase
Ref. 151221



HRC⁷⁰
High-temperature
modulating
heat pump

**Made
in France**

Manual ref: 1871442
Edition n°: 15.356



CONTENTS

1 - PLEASE READ IMMEDIATELY 4

1.1 - Important information.....	4
1.2 - Safety instructions and advice.....	4
1.3 - Delivery terms and conditions.....	5
1.4 - Storage and transport.....	5
1.4.1 - General information	5
1.4.2 - Transporting with a forklift truck	5
1.4.3 - Transporting manually.....	5

2 - INTRODUCTION..... 6

2.1 - Standard configuration	6
2.2 - Operating.....	6
2.2.1 - Heat Pump operation.....	6
2.2.2 - Pilot operation	6
2.3 - Accessories (included)	7
2.4 - Accessories available to order	7

3 - INSTALLATION..... 9

3.1 - Installing the HRC ⁷⁰	9
3.1.1 - Installation site	9
3.1.1.1 - Heat Pump installation site	10
3.1.1.2 - Condensates drainage	11
3.1.1.3 - Heater cable for external condensate drainage	11
3.1.1.4 - Protection grid for the finned heat exchanger.....	11
3.1.2 - Installing the Pilot.....	11
3.1.2.1 - Installation site.....	11
3.1.2.2 - Fitting the Pilot to the wall	12
3.1.2.3 - Fitting and placement.....	12
3.2 - Plumbing connections.....	13
3.2.1 - Hydraulic connections for the installation	13
3.2.2 - Hydraulic connection : Heat Pump circuit.....	14
3.2.3 - Heat Pump and Pilot relief valve	14
3.2.4 - Desludging.....	14
3.2.5 - Heat Pump water inlet filter (supplied)	15
3.2.6 - Heating circuit	15
3.2.6.1 - Heating circuit flow rate	15
3.2.6.2 - Backflow prevention device.....	15
3.2.6.3 - Degassing the heating circuit.....	15
3.2.6.4 - Insulating the piping	15
3.2.6.5 - Expansion vessel	15
3.2.6.6 - Frost protection and water treatment.....	15
3.3 - Installation advice for different types of transmitters and different uses.....	16
3.3.1 - For radiator / fan coil unit circuits.....	16
3.3.2 - For underfloor heating circuits.....	16
3.3.3 - For domestic hot water	16
3.3.4 - For swimming pools.....	16
3.4 - Electrical control connections.....	17
3.4.1 - Connecting the Heat Pump control.....	17
3.4.1.1 - 2-core sheathed cable	17
3.4.2 - Connecting the Pilot.....	18
3.4.3 - Temperature controls	19
3.4.3.1 - Installation precautions	19
3.4.3.2 - Room thermostat.....	19

3.4.3.3 - Outdoor temperature sensor.....	19
---	----

3.5 - Connecting to power supply..... 19

3.5.1 - Recommendations for connecting the system to the power supply.....	20
3.5.2 - Connecting the Pilot to the power supply	20
3.5.2.1 - Pilot: 230V single phase connection	20
3.5.2.2 - Pilot: 400V three phase connection	21
3.5.3 - Connecting the HRC ⁷⁰ Heat Pump to the power supply	22
3.5.3.1 - HRC ⁷⁰ Heat Pump: 230V single phase connection.....	23
3.5.3.2 - HRC ⁷⁰ Heat Pump: 400V three-phase connection	23
3.5.4 - Electrical protection for the compressors.....	23

4 - APPLIANCE CONFIGURATION 24

4.1 - Control box	24
4.1.1 - Display screen: symbols and what they mean.....	24
4.1.2 - Commonly displayed symbols.....	25
4.1.3 - Unlocking	25
4.1.4 - Language.....	25
4.2 - Installer Menu	25
4.2.1 - Selecting the right back-up for the installation.....	25
4.2.2 - <i>CONFIGURATION</i> of the HRC ⁷⁰ Heat Pump and circuits	26
4.2.2.2 - Configuring circuit 1	26
4.2.2.3 - Circuit 1 temperature control	26
4.2.2.4 - Configuring circuit 2	27
4.2.2.5 - Circuit 2 temperature control	27
4.2.3 - <i>SETTING</i> operating parameters	27
4.2.3.1 - Setting the heating curve	29
4.2.3.2 - Maintaining the target temperature (Comfort mode)	29
4.2.3.3 - Target temperature in 'Eco' mode.....	29
4.2.3.4 - Target temperature in Frost Protection mode.....	29
4.2.3.5 - Resetting installer parameters <i>205</i> to <i>230</i>	30
4.2.3.6 - Selecting the HRC ⁷⁰ Heat Pump heating capacity	30
4.2.4 - <i>FORCED COMMAND</i> of the system.....	30

5 - USE..... 31

5.1 - Setting the date and time.....	31
5.2 - Displaying the control values.....	32
5.3 - User Menu	32
5.3.1 - Setting target temperatures.....	33
5.3.1.1 - Setting the <i>AMBIENCE</i> target temperature.....	33
5.3.1.2 - Setting the <i>ECO</i> target temperature.....	33
5.3.1.3 - Setting the <i>ANTI FREEZ</i> target temperature	33
5.3.1.4 - Setting the domestic hot water temperature.....	34
5.3.1.5 - Setting the <i>SWIM. POOL</i> temperature.....	34
5.3.2 - Setting a <i>VACATION</i> period.....	34
5.3.3 - Temporary <i>OVERRIDE</i> of the programmed heating mode.....	34
5.3.4 - <i>BOOST</i> function	34
5.3.5 - Selecting <i>SUMMER / WINTER</i> mode	35
5.3.6 - Selecting the <i>LANGUAGE</i>	35
5.3.7 - <i>BEEP</i> alert.....	35
5.3.8 - Accessing the <i>INST. MENU</i>	35

6 - MAINTENANCE AND REPAIRS 35

6.1 - General information	35
6.2 - Hydraulic circuit maintenance	35
6.2.1 - Water circuit condensate drainage	35
6.2.2 - HRC ⁷⁰ Pilot.....	36
6.2.3 - Heating circuit maintenance.....	36
6.3 - Heat Pump maintenance	36
6.4 - Electrical components maintenance	36

6.5 - Checking operating temperatures	36
6.5.1 - Accessing control readings and internal / external controls	36
6.5.2 - Accessing calculated data	37
6.5.3 - Accessing the meters	38
6.6 - Errors which are not signalled by error message or alert.....	39
6.7 - Compressor start-up faults.....	40
6.8 - Alerts and errors which are signalled by the appliance.....	40
6.9 - Error messages.....	41
6.9.1 - Errors and solutions	41
6.9.2 - Operating in case of error.....	43
6.10 - Sensor data curve charts	45
6.10.1 - Water inlet and outlet HRC ⁷⁰ Heat Pump and HRC ⁷⁰ Pilot De-icing sensor	
- Air intake sensor -	
Sensors fitted to compressors 1 and 2 -	
Swimming pool sensor - DHW sensor.....	45
6.10.2 - Outdoor sensor.....	46

NOTES / MAINTENANCE 46

6.11 - Decommissioning and disposal.....	46
--	----

7 - PARTS 47

7.1 -HRC ⁷⁰ Heat Pump	47
7.2 - Electrical boxes	48
7.3 - HRC ⁷⁰ Pilot	49

8 - WARRANTY 50

8.1 - Warranty limits.....	50
8.1.1 - General information	50
8.1.2 - Cases (non limited) for exclusion from warranty	50
8.1.2.1 - Heating circuit water	50
8.1.2.2 - Handling.....	50
8.1.2.3 - Installation site.....	50
8.1.2.4 - Electrical connections	50
8.1.2.5 - Hydraulic connections	51
8.1.2.6 - Accessories	51
8.1.2.7 - Maintenance.....	51

APPENDICES..... 51

A1 - Dimensions.....	51
A1.1 -HRC ⁷⁰ Heat Pump	51
A1.2 - HRC ⁷⁰ Pilot	52
A2 - Technical data	52
A2.1 -HRC ⁷⁰ Heat Pump	52
A2.2 - HRC ⁷⁰ Pilot	53
A3 - Frost protection	53
A4 - Sizing the expansion vessel.....	54
A5 - Programming heating modes	54
A5.1 - Creating a new programme	55
A5.2 - Copying existing programmes.....	55
A5.3 - Changing a programme	56
A5.4 - View programme.....	56
A6 - Heating circuit water treatment.....	57
A6.1 - Preparing the hydraulic circuit (rinsing)	57
A6.2 - Water for filling.....	57
A6.3 - Heating circuit treatment.....	57
A6.4 - Frost protection	57
A7 - Performance tables.....	58
A7.1 - HRC ⁷⁰ Heat Pump, 17kW	58
A7.2 - HRC ⁷⁰ Heat Pump, 20kW	58
A7.3 - HRC ⁷⁰ Heat Pump, 25kW	58

Hydraulic schematic diagrams:

- 1 RADIATOR CIRCUIT- -swimming pool possible-	59
- 1 UNDERFLOOR HEATING CIRCUIT- - pool possible-.....	60
-2 RADIATOR CIRCUITS- -pool possible-	61
-2 UNDERFLOOR CIRCUITS - -pool possible-	62
-1 RADIATOR CIRCUIT/ + DHW- -pool possible-	63
-1 RADIATOR CIRCUIT + POOL-	64
-1 POOL CIRCUIT + DHW -.....	65
-1 DIRECT CIRCUIT and 1 MIXED CIRCUIT with optional 2 nd circuit	
at lower temperature (Ref.751014) -pool possible-	66
-2 DIRECT CIRCUITS and 3 rd MIXED CIRCUIT with an optional	
2 nd circuit at a lower temperature (Ref.751014) and optional	
2-way motorised valve for 1st direct circuit (Ref. 740022) -pool	
possible-.....	67

Electrical and internal wiring diagrams:

HRC ⁷⁰ Heat Pump - 17kW single phase-	68
HRC ⁷⁰ Heat Pump- 17kW three phase-	70
HRC ⁷⁰ Heat Pump- 20kW three phase-	72
HRC ⁷⁰ Heat Pump- 25kW three phase -	74
HRC ⁷⁰ Pilot electrical diagram -	76
HRC ⁷⁰ Pilot internal wiring diagram -	80

A8 - Electricity provider information form	82
--	----

1 - PLEASE READ IMMEDIATELY

1.1 - Important information

These installation and operating instructions form part of the appliances which they refer to. **In order for the warranty to be valid, they must be read before using the appliance.** This manual must be kept and passed on to successive users for future reference. It will be considered as evidence in case of litigation.

ELECTRICAL INSTALLATION RECOMMENDATIONS



- **It is the responsibility of the installer and the client to contact the electricity provider and ensure that the appliance is compatible with the power grid before connecting the HRC⁷⁰ Heat Pump (see the information form which is an appendix to this document).**
- The power grid impedance value must be less than the Heat Pump impedance Z_{max} (see § "Connecting the HRC⁷⁰ Heat Pump to the power supply").
- If electrical installation standards are not respected, irreversible damage could be sustained to the HRC⁷⁰ Heat Pump, which will not be covered by the manufacturer's warranty.

HYDRAULIC INSTALLATION RECOMMENDATIONS



- Rinse and clean the hydraulic heating circuit before connecting the Heat Pump and Pilot.
- The appliance only works when filled with water. Never switch the appliance on if it has not been properly purged and filled with water.
- The filter valve protects the Heat Pump; an annual check on the condition of the filter must be carried out.
- We recommend that you check for sludge and limescale from time to time and clean if necessary. The appliance must be switched off before any cleaning is undertaken.
- Always switch the appliance off before working on any electrical parts.
Caution: the fan may still continue to run through inertia even when the appliance has been switched off.
- Never put water on the control components or any electrical parts. Switch off the appliance before cleaning.

The high temperature Heat Pump absorbs the calories contained in outdoor air, transforms them into useful energy and transfers them to the heating water for your home. AUER cannot be held responsible for any other usage of the appliance.

The safety advice and instructions which are given here must be strictly respected.

Before making any connections, make sure that the appliances are compatible with the installation.

Before switching the system on, make sure that the network voltage to be applied to the appliances is the same as the voltage indicated on their rating plates.

Before undertaking any maintenance or handling or in case of the appliances functioning incorrectly or not at all, always disconnect from the mains power supply and seek advice from a specialist.

AUER declines any responsibility for damage caused by these instructions not being followed and any errors due to improper handling, installation or usage.

These installation and operating instructions are subject to change without prior notice.


1.2 - Safety instructions and advice

- The Heat Pump must only be installed outdoors.
- This appliance is not intended for use by people (including children) who have reduced physical, sensory or mental capacities, or by people who have insufficient experience or knowledge of the product, unless they are being supervised by someone who is responsible for their safety and in possession of the instructions on how the appliance should be used.
- Installing the Heat Pump indoors is **strictly forbidden**.
- The Heat Pump has an operating range of -20°C to 40°C. When the temperature falls below -20°C, the installation is no longer heated by the Heat Pump, but by the back-up.
- It is FORBIDDEN :
 - to let the Heat Pump run using air intake which contains solvents or explosive matter
 - to use air intake which contains grease, dust or aerosol particles
 - to connect vented exhaust hoods
- It is **FORBIDDEN** to use the appliances if the installation is not filled with water
- All work undertaken on the installation must be carried out by a qualified professional with the appliances disconnected from the mains power supply.
- This appliance must be installed in accordance with national electrical installation regulations.
- Check that the installation is equipped with a properly sized and connected ground cable.
This CE-approved unit is in compliance with the essential requirements of the following directives:
 - low voltage 2006/95/CEE (standard EN 60.335.1)
 - electromagnetic compatibility 2004/108/CEE (standard EN 55014.1 / EN 55014.2).
- Any work undertaken on the refrigerant circuit must be carried out by a qualified professional with a category 1 certificate of aptitude. It is prohibited to release refrigerant into the atmosphere: it is mandatory to recover the refrigerant before beginning any work on the circuit.

The Heat Pump uses type R290 refrigerant. Given the flammable nature of this fluid, any work done on the refrigerant circuit must be carried out using the correct equipment and in compliance with all current regulations. In case of handling the fluid (recovery, evacuation or refilling), the machine must be switched off. Do not smoke or light any flame (e.g. lighter, blowtorch) when handling the fluid. If any work needs to be undertaken on the refrigerant circuit using a flame (e.g. a blowtorch) the refrigerant must be evacuated first and replaced with nitrogen.

1.3 - Delivery terms and conditions

In general, the material is transported at the recipient's own risk. It is essential to check that all the elements have been received and that no damage has been sustained during transport upon receipt of the appliance and before beginning the installation procedure.



1.4 - Storage and transport

Acceptable transport temperatures are from -20°C to +60°C.

1.4.1 - General information

The appliances must be stored and transported in their packaging on a wooden pallet and completely empty of water.


1.4.2 - Transporting with a forklift truck

When being transported by a forklift truck, the Heat Pump must remain upright on a wooden pallet.

When moving the Heat Pump do not lift or lower the unit suddenly as it can easily lose its balance. It should also be suitably secured to prevent it from tipping over.


1.4.3 - Transporting manually

The Heat Pump can be manually transported using 2 26mmØ bars or by putting straps through the holes provided.



2 - INTRODUCTION

2.1 - Standard configuration



The group is composed of an exterior unit (Monobloc high temperature Heat Pump, to be installed outdoors only) and an interior unit (Pilot, to be installed indoors only). These units are connected together by a hydraulic connection and a communication bus.

The air to water Heat Pump collects the calories from outdoor air and transfers them to the heating water circuit with high energy efficiency.

The Pilot maintains the regulation and hydraulic distribution of the installation.

The Pilot is pre-equipped and designed for heating installations in domestic or tertiary premises.

The Pilot is pre-configured for heating a radiator circuit which is controlled from a room thermostat from the Heat Pump only.

You will need to configure the Pilot accordingly if you wish to connect it to an existing boiler (or if using electrical back-up from 0 to 6kW) or when connecting it to an underfloor heating circuit, a secondary heating circuit, a domestic hot water system or a swimming pool circuit.



NB: The Heat Pump is designed solely for heating purposes. It cannot be used for cooling.

If the required heating capacity is higher than the capacity delivered by the Heat Pump, the Pilot can provide an extra power boost, either through the boiler or its electrical back-up (0-2-4- or 6kW) depending on how much is required.


2.2 - Operating

2.2.1 - Heat Pump operation

This is a closed pressurised system in which the refrigerant serves as a medium for transferring energy.

The evaporator (4) is a refrigerating exchanger which extracts calories from the air. The humidity in the air condenses on contact with the cold surface, condenses and forms water (evacuation in (8)).

The capacitor (5), a plated heat exchanger which is hydraulically linked to the heating installation (7) via the Pilot, enables the water in the circuit and in turn the building, to be heated.



- | | |
|---------------------|---|
| 1 : Compressor 1 | 6 : Fan |
| 2 : Compressor 2 | 7 : Leaving / return point for radiator circuit |
| 3 : Expansion valve | 8 : Condensates draining |
| 4 : Evaporator | |
| 5 : Capacitor | |


2.2.2 - Pilot operation

The Pilot must always remain connected to the Heat Pump. It ensures the decoupling of the water flow from the Heat Pump and the heating circuit(s) (radiators, underfloor heating or fan coil units). It enables the degassing of the air, de-sludging and the heating installation to operate safely.

The Pilot comes pre-assembled with a removeable front panel that allows access to all the other parts of the appliance.

The 60-litre tank is made of steel and thermally insulated.

The front of the appliance is made up of an electronic display screen with control buttons and an electronic circuit board containing all the electrical connections.




2.3 - Accessories (included)

The components described below are included with the Pilot but they are not pre-assembled:

→ Outdoor temperature sensor



→ 1" valve with (500µm) built-in filter which is used to protect the Heat Pump's plated heat exchanger




Cap which enables you to access the filter when the valve is closed

→ 2 core sheathed cable linking the Heat Pump and the Pilot (lgth 10m)


It is pre-fitted to the Heat Pump, but needs connecting to the Pilot

→ 1" check valve

Between the HRC7° Heat Pump and the HRC7° Pilot




→ Hydraulic connection kit lgth 1.5m




2.4 - Accessories available to order

→ Interactive room temperature sensor enables you to control the temperature of the heating zone it is installed in (Ref. 751009)



→ Underfloor heating temperature limiter (UTL) at 65°C with manual reset for underfloor heating installations. The jubilee clips and cables are included. (Ref. 710111).



→ 2 core sheathed cable for linking the Heat Pump and the Pilot (lgth 20m)

To be used instead of the 10m-long cable which is included with the appliance (Ref. 751005)

→ Non chrono-proportional wireless room thermostat -TH^{Rnc}-

(Type on/off). Programmable thermostat with wireless radio frequency transmission (Ref. 710172). Needed when it is not possible to wire a link between the Pilot and room thermostat.

→ Anti-frost element

Used to prevent frost from forming on the inside of the condensates pipe. (Ref. 751004)

→ 2nd direct heating circuit (radiators)

Including inlet and outlet pipes, circulator pump and wiring (Ref. 751003)

→ 2nd heating circuit with motorised 3-way valve (underfloor heating)

Including inlet and outlet pipes, 3-way motorised valve, circulator pump, electronic control with 3WV leaving water and outdoor temperature sensors, room temperature corrector and underfloor heating temperature limiter (UTL) (Ref. 751007)

→ Optional control kit for swimming pools in summer

enabling you to substitute a swimming pool on circuit 1 in summer for the heating which runs on it in winter. (Ref. 751006)

→ DHW or swimming pool sensor (Ref. 710029)

3 - INSTALLATION

3.1 - Installing the HRC⁷⁰

The Heat Pump must always be transported in a vertical position, even during installation. It can be manually transported using 2 26mm Ø bars in the holes provided. Do not use the hydraulic connections to move the appliance, take hold of it using the four bottom corners.

The installation must be carried out by a qualified installer, taking all necessary precautions to avoid any risk of accident or any material damage.


3.1.1 - Installation site

The Heat Pump is specifically designed to be installed outdoors, in an open space which is not subject to excessive dust. Under no circumstances must it be installed in enclosed premises.


It is designed to operate in rain, but it can also be installed under a shelter as long as it is well ventilated (the opening should be large enough to ensure that air can flow freely to the air intake point and the air rejection point on the fan).




**ON THE GROUND OR
ON A PATIO
(open space)**




**NEXT TO A WALL
+ 3dB (A)**




**IN A CORNER
+ 6dB (A)**




**IN A YARD
+ 9dB (A)**




UNDER A WINDOW






TO THE SIDE OF A WINDOW



CORRECT







CORRECT



**THE NOISE SCREEN MUST BE MADE FROM
INSULATED MATERIALS**

3.1.1.1- Heat Pump installation site

Minimum distances to respect when installing the Heat Pump (mm).




Always make sure the heat exchanger fins are protected when moving the appliance

The Heat Pump must be handled with care and not be subjected to any impacts, especially as it is placed on the ground.



The Heat Pump must be installed on a hard and stable base which is sufficiently raised from ground level to avoid any risk of damage in case of flooding or snow.



• The Heat Pump must only be installed outdoors.

- It is **forbidden** to install the appliance in enclosed, unventilated premises.
- Do not restrict or block air intake or rejection to the fan. **No object** should impede the flow of air over the heat exchanger. The Heat Pump should be placed out of the way of prevailing winds.
- **Do not** install the Heat Pump near sources of excessive heat, combustible materials or ventilation points on adjacent buildings.
- **Do not** install the Heat Pump near kitchen or workshop outlet ducts as this could result in a mixture of oil and air settling on the heat exchanger fins and hampering its performance.
- **Do not** install the Heat Pump in areas where flammable gases or acid or alkaline substances are present as this could irrevocably damage the copper / aluminium heat exchanger.
- **Avoid installing** the Heat Pump in a location subject to noise reverberation or near to windows and corners of buildings.
- As the condensates drain trough slopes downwards, the Heat Pump must be on a level base.
- The Heat Pump must be easily accessible to facilitate inspections and maintenance.

3.1.1.2 - Condensates drainage

When the appliance is running in frost protection mode, the condensed water must be drained off. In order for the condensates to drain properly, the drainage trough and hole must be kept clean and free of any debris such as leaves or grass.

If the condensates drainage pipe is connected to the rainwater drainage system we would advise you to use a siphon.

Do not use tools to remove ice, this could damage the heat exchanger.

The Heat Pump comes with a transparent, flexible drainage pipe for the condensates (20 / 25mm Ø) which does not overlap onto the outside.

Before activating the appliance, this flexible pipe must be connected to one of the two holes which are provided for this purpose:



- Remove the back panel of the Heat Pump
- Position the pipe in the place you have chosen after drilling a hole in the grommet

a - Draining from underneath the Heat Pump

This solution is recommended for minimising the risk of ice at the condensates drainage point


b - Draining from the back of the Heat Pump

is an acceptable solution but in this case an external heater cable needs to be connected (Ref. 751004). Please refer to § "Heater cable for external condensates drainage" and also the instructions which are provided with it.



3.1.1.3 - Heater cable for external condensate drainage

The Heat Pump is built with the option of adding a heater cable to prevent any frosting on the condensates drainage circuit. This heater cable (option Ref.751004) is connected in the electrical box on the terminals marked CC on the electronics board. It must be installed in accordance with the instructions supplied with it, in or around the condensates drainage pipe, on the outside of the Heat Pump.



3.1.1.4 - Protection grid for the finned heat exchanger

The plastic grid which protects the finned heat exchanger may be removed once the Heat Pump is in position on its definitive installation site.

In order to remove the plastic grid, simply cut it away from its attachment points.

There is still a risk of damage to the fins due to external factors (for example, being close to a well-frequented walkway or thoroughfare), so it is preferable to leave the protective grid in place.

Caution: The fins are fragile and sharp. Make sure that the air passages are kept clean and free of any blockages (take care not to bend the fins when doing so).



Never clean the finned heat exchanger with a high-pressure hose or any other pressurised cleaning equipment. This could damage the fins.

3.1.2 - Installing the Pilot

3.1.2.1 - Installation site


The Pilot should be installed in premises which are protected from frost and bad weather conditions. It should be installed as close as possible to the Heat Pump and not exceed the maximum distance. The maximum distance depends on the diameter of the piping and the amount of elbows used (see the "Hydraulic connections" table). The 2-core sheathed cable which provides the bus link between the Pilot and the Heat Pump measures 10m. If needed there is a 20m option available (Ref.751005).




The Pilot weighs 110kg when filled with water. Make sure that the wall bracket can support this weight.

3.1.2.2 - Fitting the Pilot to the wall

The Pilot must be fixed vertically to a strong supporting wall using three Ø8 lag screws.



3.1.2.3 - Fitting and placement



The Pilot must be fitted at least 300mm above any obstacles to enable the hydraulic connection to be made with the bottom of the appliance.

It should be fitted at least 100mm away from the ceiling to allow easy access to the manual air valve.

It must be fitted at least 100mm away from walls on either side.

3.2 - Plumbing connections


3.2.1 - Hydraulic connections for the installation



The Heat Pump is equipped with a hydraulic pressure relief valve set at 2.5 bars. A service pressure below this value should be maintained.

In order to ensure that the fluids can circulate properly it is advisable to check that the sizing is properly adapted to the circuit between the Heat Pump and the Pilot.

All piping should be thermally insulated, especially the connecting pipes from the Pilot to the Heat Pump.



- Fit the tee along with the manual air valve onto the outgoing water outlet of the Heat Pump.
- Install two 30mm Ø flexible pipes of at least 1.5m in length to the water inlet and outlet holes on the Heat Pump (outside the building).
- Carefully insulate the pipes to minimise heat loss.
- Take care to respect a 240mm Ø minimum radius of curvature so as to avoid damaging or bending the flexible pipe.

These flexible pipes are used to decouple the Pilot from the rest of the hydraulic installation (they **MUST** be connected as the Heat Pump stands on silent blocks).

3.2.2 - Hydraulic connection : Heat Pump circuit



When the heat pump is running at full power the flow rate must be high enough to ensure that the temperature difference between the outgoing and incoming water is no greater than 5°C (take a temperature reading when the HRC⁷⁰ is in heating mode and the system is fully functioning).

The hydraulic connection section between the Heat Pump and the Pilot must be sufficient.

Using the tables below, determine the minimum inner diameter of the connection piping needed depending on the distance which separates the Heat Pump from the Pilot:

Heat pump model	17kW	20kW	25kW
Minimum nominal flow rate	1350 L/h	1550 L/h	1850 L/h
Maximum pressure	2.5 bar	2.5 bar	2.5 bar
minimum piping Ø			
if distance* between HP and control < 15m	24/26	28/30	32/34
if distance* between HP and control < 25m	28/30	32/34	36/38
if distance* between HP and control < 50m	32/34	36/38	42/44

* distance comprises full circuit



See § "Setting the 4 speeds on the circulator pump" in appendix 1895709.

Make sure that all sections of piping are fitted with functional and accessible air valves.

The hydraulic connection between the Heat Pump and the Pilot can be made using steel, copper or PEX piping with a diameter of at least 1".

The hydraulic kit must be fitted using flexible piping on the water inlet and outlet points of the Heat Pump in order to prevent any vibrations being transmitted to the heating system.

3.2.3 - Heat Pump and Pilot relief valve


The Heat Pump and the Pilot are both fitted with a pressure relief valve.

The pressure relief valve on the Heat Pump sets the maximum acceptable pressure in the installation (2.5 bars when hot). The maximum service pressure on the Heat Pump must, consequently, be lower than 2.5 bars.

Example : If the Heat Pump is positioned 5m below the Pilot, the pressure reading on the Pilot would be 0.5 bars less than the real pressure of the water in the Heat Pump. In this case, the maximum pressure for the Pilot would be 2 bars. Therefore it would be advisable to fill the heating circuit at an intermediary pressure (between 1 and 1.5 bars).

In case of operating with boiler back-up these relief valves **MUST** be fitted in addition to the ones which the boiler is already equipped with.

The connections and evacuation conduits for the pressure relief valves must be made from materials which are resistant to high temperatures and corrosion.



3.2.4 - Desludging

The Pilot has an integrated desludging function which collects oxides, scale and other particles which become detached from the inner walls of the heating circuit. The lower part of the system is equipped with a sludge valve which should be briefly activated once a year (see § "Maintenance and Repairs").

For underfloor heating installations, we would advise you to fit a settling tank, which will complement the actions taken by the Pilot.

3.2.5 - Heat Pump water inlet filter (supplied)

A 1" valve with a built-in 500µm filter must be fitted to the water inlet piping on the Heat Pump:

- Respect the flow direction of the filter (arrow on the valve)
- Install the 1" valve with filter on the inside of the building and ensure it is thermally insulated



Clean the filter several times as soon as the Heat Pump circulator pump has been activated (take care to switch the circulator pump off before cleaning).

- Clean the filter at least once a year.

3.2.6 - Heating circuit



- **It is essential to fit the 500µm particle filter which is supplied with the Pilot in order to prevent any clogging or dirt build-up in the heat exchanger.**
- **Before making the hydraulic connection for the Heat Pump the installation must be desludged and rinsed.**

3.2.6.1 - Heating circuit flow rate



- For heating circuits with radiators, fan coil units or underfloor heating:
The flow rate must be sufficient to ensure that the difference in temperature between the leaving and return points is not over 15K in radiator or fan coil unit circuits or 7K in underfloor heating circuits.
For installations which have thermostatic valves, this test must be carried out with all valves open.

The heating capacity from the heat radiating sources determines the heating water flow rate and allows you to check that the sections, lengths and layout of the hydraulic distribution network are compatible with the Pilot circulator pump.

Adjust the speed (I, II or III) of the UPS 20-60 circulator pump which is fitted to the Pilot to the characteristics of the hydraulic circuit using the curve chart below: flow rate Q (m³/h) / pressure head H (mCE).



For underfloor heating installations, the piping for the heating circuit must not be under 1" in diameter.



See § "Setting the 4 speeds on the circulator pump" in appendix 1895709.

3.2.6.2 - Backflow prevention device

French law (articles 16.7 and 16.8 of the "Règlement Sanitaire Départemental") stipulates that a type CB backflow prevention device must be fitted. This device must be at different, non-regulated pressure zones, in accordance with the NF P 43-011 standard. This is also an obligatory requirement in other countries so it is important to check the current laws and standards in the country of installation and ensure that your installation is in compliance with them. The backflow prevention device is designed to prevent incoming heating water from going into the drinking water circuit. It must be connected to mains drainage.

3.2.6.3 - Degassing the heating circuit

All necessary measures must be taken to ensure that the installation can be continuously degassed. Automatic air valves should be placed at each high point of the installation and manual air valves should be fitted on each radiator.

3.2.6.4 - Insulating the piping

Insulants must comply with DTU 67.1 or the current regulations in the country of installation.

All visible piping and accessories (circulator pump, expansion vessel, valve, etc...) must be insulated. Remember to insulate the distribution manifolds and the return and leaving flow pipes to the underfloor heating circuit and also the piping which connects the Heat Pump to the Pilot.

3.2.6.5 - Expansion vessel

An expansion vessel needs to be fitted onto the heating circuit. See Appendix 4 for help on sizing.

3.2.6.6 - Frost protection and water treatment

See appendices A3 et A5.

3.3 - Installation advice for different types of transmitters and different uses

3.3.1 - For radiator / fan coil unit circuits

Thermostatic valves: these valves must primarily be used for premises which receive high quantities of free calories from sunlight. In an installation where only thermostatic valves are used there **must** be a bypass function in place (e.g. a differential valve).

In an installation with thermostatic valves and a room temperature sensor, the room or area where the room temperature sensor is located **MUST** have manual air valves fitted on the radiators.

In order to ensure full satisfaction from your room thermostat is essential to follow the installation and assembly instructions when setting it up.

3.3.2 - For underfloor heating circuits




It is MANDATORY to fit an underfloor heating temperature limiter on the outgoing water point of each circuit.

It is not necessary to drain the tank.

- Adjust setting 207 to a value which is equal to or below 50°C (see "Regulator settings").
- Replace the electrical bridges between terminals 4 and 5 for circuit 1 and between terminals 1 and 2 for circuit 2 used in the underfloor heating for the temperature limiters (UTL).

These aquastats cut off the power supply to the underfloor heating circulator pump on circuits 1 (HPCP 1) and 2 (HPCP 2) in case of abnormally high temperatures on the underfloor heating circuit.



- 1 - Position the temperature limiter (UTL) at the desired point
- 2 - Place the bulb on the heating water outgoing water point pipe
- 3 - Use the clip to hold the bulb in place
- 4 - Fix the insulant around the bulb
- 5 - Remove the pre-fitted electrical bridges:
 - between terminals 4 and 5 for circuit 1
 - between terminals 1 and 2 for circuit 2
- 6 - Make the electrical connections for the underfloor temperature limiter (UTL) on terminals:
 - 4 and 5 for circuit 1
 - 1 and 2 for circuit 2

3.3.3 - For domestic hot water

Domestic hot water can be produced by the Pilot. The hot water tank is heated by a primary water circuit which is connected to the Pilot (circuit 2)(Accessories : "2nd circuit at an identical temperature"-Ref. 751003- and "DHW sensor" -Ref. 710029-).

It is important to equip the hot water tank with a suitably powerful heat exchanger (minimum 40kW).

To ensure an effective coupling with the Heat Pump the surface of the water tank's primary heat exchanger must be at least 1.5m².



Using a water tank where the primary heat exchanger is around 25kW (1.5m²) can lead to Heat Pump malfunction because of on / off cycles which are too long.

The domestic water circuit must be installed in compliance with regulations and best practices. It is particularly important to observe the following instructions:

- A pressure relief valve must be fitted onto the cold water inlet on the tank
- Do not fit a shut-off valve between the pressure relief valve and the tank.

NB : the pressure relief valve may let out a small amount of water when the DHW is being reheated: this is normal.

- In order to prevent this run-off if the pressure exceeds 4 bars:
 - Fit a pressure reducer on the cold water inlet
 - Fit a DHW expansion vessel between the pressure relief valve and the tank.
- The number of elbows used and drops in pressure must be minimised, the plumbing fixtures used must be adapted to the installation.
- In regions where high levels of limescale are present in the water (TH > 15), we would advise you to fit an anti-scale device on the cold water inlet. The TH should be under 15.
- The concentration of chloride in domestic hot water should be less than 60mg/L (quality level required for drinking water for human consumption).



As the domestic hot water can reach temperatures of over 60°C (notably to protect against legionellosis), a thermostatic mixing valve **MUST be fitted onto the DHW outgoing point to avoid risk of scalding.**

3.3.4 - For swimming pools

For a non-permanent pool please refer to the instructions provided with the control kit for summer pools (Ref. 751006).

THE CONTROL KIT FOR SUMMER POOLS MUST NOT BE USED FOR A PERMANENT POOL (SUMMER + WINTER).

3.4 - Electrical control connections

3.4.1 - Connecting the Heat Pump control

3.4.1.1 - 2-core sheathed cable

The Heat Pump is pre-fitted with a non-polarised 2-core sheathed cable (communication bus). This 10m cable is supplied with and pre-connected to the Heat Pump. It must be connected to the Pilot.

If the connection needed is longer than 10m, replace this cable with a 20m cable, which is available to order (Ref. 751005).




Diagram of connection to Pilot without the connection cable braided shielding on the Pilot being grounded.



Diagram of connection to the Heat Pump with MANDATORY grounding of the connection cable braided shielding (faston terminal near 2-point connector).

- On the Pilot, cut the bus link to the right length: LOOPS ARE FORBIDDEN.
- On the Pilot, cleanly remove 10cm of the shielding to prevent any short circuits.
- Connect the two wires (stripped to 10 mm) to the Pilot.
- **IMPORTANT:** DO NOT connect the bus link shielding to the ground of the Pilot.

3.4.2 - Connecting the Pilot

For a standard installation with one radiator circuit, the outdoor temperature sensor ^(a) and if applicable the room thermostat ^(b).

Screw terminal blocks for connection to the Pilot electronics board

1.12-point terminal (the circuit board marked Ext. ; Pisc. ; Amb 1 ; Amb 2 ; Del ; HP/HC)

Ext.^(a) : Outdoor sensor (supplied, mandatory connection)

Pisc.^(b) : Swimming pool aquastat or sensor. See § "Circuit 1 temperature control" to set the circuit 1 swimming pool sensor ⁽¹⁾

Amb 1 : Circuit 1 room thermostat (potential-free dry contact, non chrono-proportional, no IPD, etc...) or room temperature sensor with display for circuit 1 to set the circuit 1 temperature control or to control the swimming pool flow for circuit 1 ⁽¹⁾

Amb 2 : Circuit 2 room thermostat (potential-free dry contact, non chrono-proportional, no IPD, etc...) or circuit 2 DHW aquastat
See § "Circuit 2 temperature control" to set ambient temperature or DHW temperature on circuit 2

Del : Load shedding input, used to partially or completely stop electrical back-up and the Heat Pump when the electricity is needed for other household uses.
Remove the existing electrical bridge and connect the load shedding device's potential-free dry contact.
Set to parametre PAR.218 ⁽²⁾ (see § "Setting operating parametres") which determines the level of authorisation for the electrical back-up and Heat Pump to run at (the factory setting is total load shedding for the Heat Pump and electrical back-up).

HP / HC : Peak-time / off-peak operation, used to stop partial or full operation of the electrical back-up and Heat Pump during peak hours.

Remove the existing electrical bridge and connect the potential-free dry contact PT/OP.

Adjust to setting PAR.217 ⁽²⁾ (see § "Setting operating parametres") which determines the level of authorisation for the electrical back-up and Heat Pump to run at (the factory setting is only for load shedding on the electrical back-up).

The HP / HC and DEL contacts can also be used for load shedding on peak day pricing. By programming PAR.217 or PAR.218 on 7, only the boiler will run when the dry contact is open.

⁽¹⁾ : For a permanent swimming pool (summer + winter).

If the pool is not permanent, please use the summer swimming pool control kit (Ref. 751006).

⁽²⁾ : If both settings PAR.217 and PAR.218 are activated at the same time, the lowest authorisation level will be used on both inputs in case of simultaneous load shedding.

2. 2-point terminal (marked Chaud on PCB.)

Chaud. : on / off output (dry contact) to connect to the room thermostat input on the existing boiler.
see § "Back-up section" for setting the boiler back-up.


The boiler normally commands its own circulator pump.

If this is not the case, relay the "chaud" dry contact so that one relay feeds two contacts:

- the first contact (NO) is used to start the burner on the boiler (room thermostat input).
- the second change-over contact is used to supply the boiler's heating circulator pump and to keep it running a few minutes (approx.5) after the boiler has stopped.

3. 2-point terminal (marked BUS on PCB)

BUS : Link between HRC⁷⁰ Heat Pump / HRC⁷⁰ Pilot by 2-core sheathed cable (10m cable supplied, 20m cable available on order Ref. : 751005).



• In order to avoid any problems which may occur when reading the temperature sensors, wire the control independently of any power cables (raceways) and avoid distribution boxes.

- The conductors must be made from electrolytic copper (there must be no rust on the stripped connection strands).**
- Telephone wire must not be used (too brittle for connections).**
- The diameter of the control cables must be between 0.5 and 1mm².**

3.4.3 - Temperature controls

3.4.3.1 - Installation precautions

Where an installation includes thermostatic valves and a room thermostat or room temperature sensor the area where the room thermostat or room temperature sensor is installed **MUST** have radiators equipped with manual valves.

The temperature control must be positioned on an interior wall of the premises to be controlled by the appliance.

It must not be installed on an outdoor wall.

Do not position the temperature control near to a window, a curtain or a door. Avoid installing it in an alcove, a cupboard or behind wall coverings or hangings.

Do not place it above a heat source (e.g. radiator, fireplace) or on a wall which has a chimney behind it.

Do not place it in strong sunlight or in strong lighting.

Fit the sensor at 1.5m from ground level and at least 50cm from neighbouring walls. Insulate the end of the electric sheath connecting it to the appliance to prevent any draughts from affecting the reading.

3.4.3.2 - Room thermostat



Only connect one of the following:

- ROOM TEMPERATURE SENSOR with DISPLAY (Ref. 751009)
- WIRELESS ROOM THERMOSTAT (Ref. 751010)

Any other type of chrono-proportional thermostat could cause a malfunction and thus render the warranty null and void.

3.4.3.3 - Outdoor temperature sensor

It is mandatory to fit an outdoor temperature sensor.

Position the sensor on the coldest outside wall of the building (in general this is the north-facing wall). It should not be exposed to morning sunlight.

It is preferable to position the outdoor sensor in the middle of the wall or heating zone at a minimum of 2.5m above the ground.

Avoid placing the sensor:

- above windows, doors, air vents or any other heat sources
- Under balconies or gutters. In order to avoid errors in readings due to air circulation, insulate the end of the electric sheath where it connects to the sensor. Do not paint the outdoor sensor.

3.5 - Connecting to power supply

Make sure that the power supply is sufficient to supply both the Heat Pump and if necessary the electrical back-up, taking into account any other domestic usage of the electricity. Power supply connection for each appliance must be done by a qualified professional with mains power switched off.



Your country's current rules and regulations MUST be respected (Standard C15-100)

- **The electric lines for general power supply to the circuits must be made in compliance with your country's current rules and regulations (standard C15-100).**
- **Standard C15-100 determines the cable section to be used depending on acceptable currents.**
- **Standard C15-100 determines the cable section to be used depending on the following factors:**
 - **Nature of the conductor:**
 - type of insulant, number of strands, etc...
 - **Installation mode:**
 - influence of conductor and cable groups
 - ambient temperature
 - length of cables, etc...



• During transport electrical cables may accidentally loosen

- **To prevent any risk of abnormal overheating check that the faston terminal connections are secure and that the screws are properly tightened. See § "Parts - electrical boxes"**

Each appliance is pre-wired. However, it is necessary to connect the following elements to the relevant terminals:


- Electricity supply to the power circuit of each appliance, separately: the Heat Pump and the Pilot.
 - The sensors, thermostat and load shedding device on the Pilot.
 - The sheathed connection cable (2 core) between the Heat Pump and the Pilot (10m cable supplied).
- Under no circumstances will the manufacturer be held responsible for any consequences which may arise due to incorrect choice or installation of power cable sections.

Terminal strip

The terminal strips are spring-loaded cage clamps. For handling, use one of the following:

- for 2.5mm² control terminals or 4mm - 6mm power terminals (tetra) use a 3.5 x 0.5 flat-head screwdriver
- For the 10mm² mains power terminals, (single phase), use a 5.5 x 0.8mm flat-head screwdriver

- 1 : Introduce the screwdriver into the window just above or below the identification number
- 2 : Insert the wire into the open cage clamp
- 3 : Remove the screwdriver.



N.B: The wires must be stripped to the following lengths:

- between 10 and 12 mm for 2.5mm control terminals
- between 18 and 20mm for the mains power terminals
- between 11 and 13mm for the intermediary power terminals

3.5.1 - Recommendations for connecting the system to the power supply

Check:

- The input current
- The number and thickness of power cables
- Fuse or circuit breaker ratings

The power supply must come from an electrical protection and sectioning device which complies with all current rules and regulations. This CE-stamped appliance complies with the essential requirements of the following directives:

- Low voltage n°2006/95/CE
- EMC n° 2004/108/CE

Check the the installation is equipped with a correctly sized and connected ground cable.

Check that the voltage and frequency of the general power supply fit requirements. The amount of variation in voltage permitted is:

230 V -10% à +6% 50Hz for single phase models + ground cable
400 V -10% à +6% 50Hz for three-phase models + neutral + earth cable.

3.5.2 - Connecting the Pilot to the power supply


The Pilot must be protected beforehand by an all-pole circuit breaker (minimal distance to separate contacts = 3mm: EN 60 335-1) using either fuses or a thermal magnetic circuit breaker calibrated to the right power for the Pilot.

Type of back-up	Pilot		
	Without back-up or boiler back-up	6 kW electrical back-up	
Power supply voltage	230 V mono	230 V mono	400V tri
Current absorbed	2 A	30 A	10 A
Fuse calibration for mains switch ⁽¹⁾	32 A	32 A	12 A
Power supply by phase ⁽²⁾	6 mm ² min. to 10 mm ² max.		2.5 mm ² min. to 4 mm ² max.
Number of conductors ⁽²⁾	2x6 mm ² + T ^(*) min. to 2x10 mm ² + T ^(*) max.		4x2.5 mm ² + T ^(*) min. to 4x4 mm ² + T ^(*) max.

⁽¹⁾ or general bipolar or tetrapolar circuit breaker

⁽²⁾ The figures given here are indicative. They should be checked, and if necessary adjusted, depending on the installation conditions and current standards.

^(*) The width of the ground cable should be equal to the width of the largest cable.



To access the terminals, remove the front faceplate of the Pilot and open the control box by removing the two screws (1).


N.B: See electrical diagram in the appendix.

3.5.2.1 - Pilot: 230V single phase connection



The HRC⁷⁰ Pilot is set for 400V three-phase use.


For 230V single phase use, you will need to fit a bridge (supplied in a small package) between the three phase terminals. See diagram below.




PH-N : Phase/Neutral 230V single phase - 50Hz power supply
CPAC : Heat Pump circulator pump, pre-connected
Cchauf 1 : Circulator pump for heating circuit1 or primary pump for swimming pool circuit
Cchauf2 : Circulator pump for heating circuit 2
ou ECS : Primary circulator pump for domestic water circuit
LTP1/LTP2 : Temperature-limiting safety aquastat (65°C) with manual reset. It **must** be placed at the start of the underfloor heating circuit (not supplied).



Make sure the bridge is properly pushed into place. See below:



3.5.2.2 - Pilot: 400V three phase connection



L1-L2-L3-N : Power supply Phase/Neutral 400V three-phase 50Hz
 CPAC : Heat Pump circulator pump, pre-connected
 Cchauf 1 : Circulator pump for heating circuit 1
 ou Pisc : or primary circulator pump for swimming pool circuit
 Cchauf2 : Circulator pump for heating circuit 2
 ou ECS : Primary circulator pump for domestic water
 LTP1/LTP2 : Temperature-limiting safety aquastat (65°C) with manual reset. It must
 be fitted at the start of the underfloor heating circuit (not supplied).

3.5.3 - Connecting the HRC⁷⁰ Heat Pump to the power supply



ELECTRICAL INSTALLATION RECOMMENDATIONS

- It is the responsibility of the installer and the client to contact the electricity provider and ensure that the appliance is compatible with the power grid before connecting the HRC⁷⁰ Heat Pump (see the information form which is an appendix to this document).
- The power grid impedance value must be less than the Heat Pump impedance Z_{max} (see § "Connecting the HRC⁷⁰ Heat Pump to the power supply").
- If electrical installation standards are not respected, irreversible damage could be sustained to the HRC⁷⁰ Heat Pump, which will not be covered by the manufacturer's warranty.

The HRC⁷⁰ Heat Pump is CE-marked. It complies with the French standard NF C15-100 and the European standards EN 61000-3-3 et EN 61000-3-11, among others.

It is equipped with soft starters, which limit the start-up current to 45A for single phase and 60A for three phase.

The power supply cable should be carefully sized according to the following factors:

- maximum current
- the distance between the HRC⁷⁰ Heat Pump and the power supply source
- overall protection
- the neutral operating system


Take care to strip the cable before pushing it into the terminals, and make sure that the copper is in good condition.

A means of disconnection must always be fitted in compliance with the installation rules.

If the power supply cable is damaged it must be replaced by suitably qualified professional.

To access the terminals, remove the panel on the bottom left hand side (2 screws) and open the electrical box (8 screws).

The electrical power supply cable should first be inserted through an exterior compression gland and then through a cable grommet on the electrical box.




	HRC ⁷⁰ Heat Pump			
HRC ⁷⁰ heat pump model	HRC ⁷⁰ 17kW single phase	HRC70 17kW three phase	HRC70 20kW three phase	HRC70 25kW three phase
Power supply voltage	230 V single phase	400 V three phase	400 V three phase	400 V three phase
Maximum power consumption	6.5 kVA	6.5 kVA	7.5kVA	9 kVA
Maximum current requirements	35 A	13 A	15 A	18 A
Maximum start-up current ⁽¹⁾	45 A	48 A	48 A	60 A
Compressor soft starter?	YES	NO	NO	YES
Phi tangent when Heat Pump starts up	1.53	2.46	2.46	2.37
Heat Pump (Z _{max}) impedance (ohm)	0.181	-	-	-
Phase impedance (Z _{max}) (ohm)	-	0.248	0.248	0.175
Neutral impedance (Z _{max}) (ohm)	-	0.166	0.166	0.117
Heat Pump regulation mode	Fixed speed	Fixed speed	Fixed speed	Fixed speed
Number of power stages	3	3	2	3
Circuit breaker size	40A single phase	16A three phase	16A three phase	20A three phase
Power supply by phase ⁽²⁾	10 mm ²	4 mm ²	4 mm ²	6 mm ²
Number of conductors ⁽²⁾	2 x 10mm ² + T ^(*)	4 x 4mm ² + T ^(*)	2 x 10mm ² + T ^(*)	4 x 6mm ² + T ^(*)
Number of conductors (2)	See "Connecting the Pilot to the power supply" table			

⁽¹⁾ D-curve bipolar or tetrapolar general circuit-breaker


⁽²⁾ The figures given here are indicative. They must be checked and modified if necessary according to conditions of installation and current rules and standards.
If the length of the cable exceeds 15m or if the network could be subject to drops in voltage over 10V, use a thicker cable.

^(*) The width of the ground cable must be equal to the thickest part of the power supply cable.

3.5.3.1 -HRC⁷⁰ Heat Pump:230V single phase connection




3.5.3.2 -HRC⁷⁰ Heat Pump: 400V three-phase connection



• Three-phase monitor relay for the HRC⁷⁰ Heat Pump (17kW, 20kW and 25kW)

A phase monitor relay is installed to prevent a phase failure, which could damage the compressors. If the phases are reversed, it will stop the power supply to the Heat Pump.

CORRECT WIRING



INCORRECT WIRING



In case of INCORRECT WIRING:



Warning: never work with live voltage!

If the phase order is reversed or there is a phase missing, the relay cuts the power supply to the circuit board. A «BUS ERR» error message will appear. This is indicated on the phase monitor relay by the orange light at the top being off and the green light at the bottom being on. To correct the error, reverse the two phases on the mains power terminal.

When the Pilot is switched on, a «BUS ERR» error message will be displayed. Reverse the two phases on the three-phase power cable of the Heat Pump. Switch the power back on and check the voltage on each phase.

3.5.4 - Electrical protection for the compressors

The HRC⁷⁰ Heat Pump is equipped with a soft start-up device to limit the intensity of the current when the motor starts up, in compliance with the limits set by the NF C 15 100 standard (45A per phase for single phase and 60A per phase for three-phase).



The electrical protection devices for the compressors constantly monitor the current and voltage. In case of over voltage, under voltage or an abnormally high current, the compressor will be stopped.


• Soft start-up device for the HRC⁷⁰ Heat Pump when using a single phase system

The soft start-up device constantly monitors the compressor by measuring the current and voltage. In case of over voltage, under voltage or an abnormally high current, the compressor will be stopped.

How it works:

- The soft start-up device controls the start-up phase until the motor reaches its stable operating speed.
- If the motor cannot start, it is because the power supply has been cut off by the soft start-up device.

In order to protect the compressor, the motor will not be able to start up again until 5 minutes after it has been stopped.



Start-up errors:

- If the compressor fails to start up, two lights (green and red) will flash to indicate that there is an error (see § "Compressor start-up errors").


• Soft start-up for the HRC⁷⁰ Heat Pump when using a three-phase system (25kW)

The soft start-up device also serves to control the phases (phase order or missing phase, which could damage the compressor).

If the phase order is reversed or a phase is missing the relay cuts off the power supply to the compressor. This error is indicated by the light flashing once per second.

The soft start-up device controls the power supply voltage. If it is less than 195V, the compressor will either fail to start or switch off. The error is indicated by a fast-flashing light (10 flashes per second).

In case of a compressor error, (overcurrent, short circuit or an error on the start-up device itself) the error is indicated by the light flashing on for five seconds and then off for five seconds.



4 - APPLIANCE CONFIGURATION



- For 25kW and 20kW HRC⁷⁰ Heat Pumps: It is mandatory to configure the HRC⁷⁰ Pilot (Installer Menu, Configuration).
- The HRC⁷⁰ Pilot is pre-configured for a 17kW HRC⁷⁰ Heat Pump.

- All work carried out on the water circuits and electrical installations must be carried out by a qualified professional and in accordance with current rules and regulations.
- Fill the installation with water and treat the water.
- Purge the heating circuits (open the air valves situated on the highest points of the installation until all trapped air has been released).
- Check that all circuits are properly sealed.
- Check that the power supply voltage is correct at the mains switch.
- Check that all hydraulic connections have been properly tightened and that there are no leaks.
- Check that all the valves are open, that there is water in the heating circuit and that nothing is stopping the water from circulating freely in the heat exchanger and the hydraulic circuit.
- Check that the sludge valve is correctly fitted and that nothing is blocking its screen filter.
- Once all of these checks have been carried out, switch the appliances on.
- Configure the installation.

The appliance is pre-configured for the following system:

- 17 kW Heat Pump
- Heat Pump without back-up (neither boiler or electrical)
- 1 radiator circuit
- 1 room thermostat to control radiator circuit temperature

If necessary, this configuration can be modified using the "Installer" menu.




N.B: Frost protection for the Heat Pump

When the Heat Pump is switched off (temporarily or definitively), and the temperature of the outgoing water from the Heat Pump falls below 5°C, the circulator pump starts up and will only stop running when the water temperature reaches 11°C.




The installation must NEVER be switched on WITHOUT WATER in the heating circuit

4.1 - Control box



4.1.1 - Display screen: symbols and what they mean




Day of the week

Display zone for time and temperature


9-character message

Symbol	Meaning
	Summer mode in progress
	Heat Pump running at 1st power level (compressor 1 running, fan running at speed 1)
	Heat Pump running at 2nd power level (compressor 2 running, fan running at speed 2)
	Heat Pump running at 3rd power level (compressors 1 & 2 running, fan running at speed 3)
	De-icing in progress
	Electrical back-up is running
	Boiler back-up request
	Heat Pump circulator pump running
	Heating circuit 1 circulator pump running
	Heating circuit 2 circulator pump running
	Domestic hot water production in progress
	Setting / Setting display
	Time or programme is being set
	Comfort mode
	Economy mode
	Frost protection mode
	Holiday mode

4.1.2 - Commonly displayed symbols




Example 1



- Tuesday
- Circuit 2 in use for domestic hot water
- Heat Pump running at third power level
- Water temperature at leaving point (of primary domestic water circuit): 62°C
- Pressure: 1.3 bars

Example 2




- Thursday
- Holiday mode in progress
- Holiday mode set to end in 14 days


4.1.3 - Unlocking


- Once the appliance has been switched on, or if the control box hasn't been used for more than 30 minutes, the control box will automatically lock. When in locked mode, the buttons become inactive.

- **To unlock the control box, press  and hold down for 4 seconds.**

4.1.4 - Language

- Press .
- Turn dial to scroll through menu choices:



- Press  to return to main screen.

4.2 - Installer Menu

Accessing the installer menu:


- Press .
- Turn dial until "INST. MENU" appears on screen
- Press  and .
- **Hold them down simultaneously** for 3 sec.

- | | |
|-----------------|---------------------|
| - BACK UP | - DATA CALCULATIONS |
| - CONFIGURATION | - COUNTERS |
| - SETTINGS | - MANUAL |
| - DISPLAY | - RESET PARAMETRES |


Access:

- values measured
- temperatures calculated
- programmed time periods
- counters / meters

4.2.1 - Selecting the right back-up for the installation




When the "HP + ELECT" or "ELECTRIC" options are offered, two warning screens will appear:



These screens serve to alert you to the fact that you are about to activate the electrical back-up


⚠ Is the HRC⁷⁰ Pilot cable wide enough?
Check in the § "Connecting the Pilot to the power supply" section to ensure that the diametre of the power supply cable is large enough to support the strength of the electrical current used by the appliance.



The option you select will only be activated after you have confirmed it.

4.2.2 - CONFIGURATION of the HRC⁷⁰ Heat Pump and circuits

The "CONFIGURATION" sub-menu allows you to choose the Heat Pump model as well as the type of circuit and type of controls fitted. The settings specific to each configuration are automatically adjusted by the software. See the hydraulics diagrams in the appendices.




4.2.2.1 - Heat Pump model


Select the heat pump model that you have installed.

The different models of heat pump appear in the following order:


HRC⁷⁰ - 17 / HRC⁷⁰ - 25 / HRC⁷⁰ - 20 / HRC⁷⁰ - 35
HRC⁷⁰ - 7 / HRC⁷⁰ - 11



4.2.2.2 - Configuring circuit 1



4.2.2.3 - Circuit 1 temperature control




NB: If circuit 1 is an underfloor heating circuit, it is mandatory to fit a temperature control.



Connect one of the following ONLY:

- TEMPERATURE SENSOR with DISPLAY (Ref. 751009)
 - ROOM THERMOSTAT (Ref. 710172)
- Any other thermostat could cause a malfunction and thus render the warranty null and void.**


4.2.2.4 - Configuring circuit 2



- (1) It is only possible to have radiators for circuit 2 when circuit 1 is also a radiator circuit (or deactivated)**
- (2) It is only possible to have underfloor heating for circuit 2 when circuit 1 is also an underfloor heating circuit (or deactivated)**
- (3) It is only possible to have domestic water for circuit 2 when circuit 1 is also a domestic water circuit (or deactivated)**


4.2.2.5 - Circuit 2 temperature control

To select the temperature control or domestic water temperature control for circuit 2.



N.B: If circuit 2 is an underfloor heating circuit it is mandatory to fit a temperature control.

If circuit 2 is configured for domestic hot water production the two following options are available:




Connect ONLY:


- Room thermostat (Ref. 710172)

Any other thermostat could cause a malfunction and thus render the warranty null and void.

4.2.3 - SETTING operating parametres

Installer parametres *PAR205* to *PAR230*



- Turning the dial towards + increases the parametre or setting number
- Turning the dial towards - decreases the parametre or setting number
- Press  at any time to return to initial "SETTINGS" screen

See the full list of parametres in the table on the next page:

Use	Parametre	Function	Unit	Operating range	Factory setting
1 heating circuit only	PAR.205	Heating circulation controlled by the room temperature controller		0 = circulator pump runs constantly	0
				1 = circulator pump controlled	
				2 = circulator pump runs constantly even with no heating request	
Heating curve parametre	PAR.207	Max. heat pump water temperature	°C	PAR.208 to 70°C	70°C
Heating curve parametre	PAR.208	Min. heat pump water temperature	°C	20°C to PAR.207	30°C
Heating curve parametre	PAR.209	Max. outdoor temperature	°C	15 TO 25°C	20°C
Heating curve parametre	PAR.210	Min. outdoor temperature	°C	-20 TO 0°C	-10°C
	PAR.211	Difference between target temperature and maintained temperature	K	0 TO 30K	4K
	PAR.213	To lower heating curve in ECO mode periods	K	0K TO PAR.214	10K
	PAR.214	To lower heating curve in frost protection mode periods	K	PAR.213 TO 40K	20K
For heating circuit(s) only	PAR.215	Summer / winter mode time delay	hour	0 TO 48H	12H
For heating circuit(s) with temperature control	PAR.216	Heating advance when switching from "Holiday" mode to "Comfort" mode		YES / NO	NO
Remove electrical bridge (HP/HC) from hydro-electronic control and connect HP/HC electricity provider contact	PAR.217*	Authorisation level for stopping heat pump and electrical back-up from operating during peak time (HP / HC input)		0 = No operation authorised	0
				1 = heat pump level 1 authorised	
				2 = heat pump level 2 authorised	
				3 = HEAT PUMP AUTHORISED	
				4 = heat pump authorised and level 1 electrical back-up	
				5 = HEAT PUMP AND LEVELS 1 & 2 ELECTRICAL BACKUP AUTHORISED	
				6 = Authorised to operate fully	
				7 = Boiler authorised only	
Remove electrical bridge (HP/HC) from hydro-electronic control and connect the load shedding contact	PAR.218*	Authorisation level for stopping heat pump and electrical back-up from operating during peak time (DEL input)		0 = No operation authorised	3
				1 = heat pump level 1 authorised	
				2 = heat pump level 2 authorised	
				3 = HEAT PUMP AUTHORISED	
				4 = heat pump authorised and level 1 electrical back-up	
				5 = HEAT PUMP AND LEVELS 1 & 2 ELECTRICAL BACKUP AUTHORISED	
				6 = Authorised to operate fully	
				7 = Boiler authorised only	
Circuit 2: domestic water circuit with domestic water sensor (circuit 1 must be a radiator circuit) or deactivated	PAR.219	If there is a domestic water sensor: Differential sanitary heat demand	K	1 TO 10K	7K
		If there is a domestic water aquastat: Heat pump target temperature	°C	60°C	60°C
	PAR.220	DHW sharing		0 = DHW heated as priority	1
				1 = Heating time shared between DHW and heating	
	PAR.221	Anti-legionellosis cycle (IDHW is heated to 6°C every X days at 10pm)	days	0 = DHW heated as priority	0
Swimming pool circuit on circuit 1 in addition to the heating circuit and swimming pool kit connected to the hydro-electronic control	PAR.222	Differential between heat pump target temperature and swimming pool target temperature (a gap which fixes the heat pump target temperature above the swimming pool target temperature)	K	0 TO 20K	5K
	PAR.223	Swimming pool heating advance before leaving "Holiday" mode	days	from 0 = no advance to 7 = 7 days	1 DAY
	PAR.224	Number of recording sequences per USB file	128mn sequence	1 to 255 sequences (of 128mn)	255
	PAR.225	Data recording period	mn	1 TO 240	1
	PAR.230	Choice of compressor		0 ; 1 OR 2	0


*If parametres PAR.217 and PAR.218 are both activated at the same time, the lowest authorisation level will be used on both inputs in case of load shedding

s

4.2.3.1 - Setting the heating curve


Parametres *PAR207* to *PAR210* enable you to adjust the heating curve to the mode and level you require.

- *PAR207* = Max. Heat Pump temperature (°C) to min. outdoor temperature (*PAR210*)
- *PAR208* = Min. Heat Pump temperature (°C) to max. outdoor temperature (*PAR209*)
- *PAR209* = Max. outdoor temperature (°C)
- *PAR210* = Min. outdoor temperature (°C)



Standard radiator settings:

- *PAR207* = 60°C
- *PAR208* = 30°C
- *PAR209* = 20°C
- *PAR210* = -10°C




Standard underfloor heating settings:

- *PAR207* = 45°C
- *PAR208* = 20°C
- *PAR209* = 20°C
- *PAR210* = -10°C

4.2.3.2 - Maintaining the target temperature (Comfort mode)

When position 2 of *PAR205* is selected (*PAR205* = 2), the difference between the target temperature and the lower temperature at which heating will automatically re-start can be adjusted using *PAR211*. An indoor sensor is required to monitor the temperature for this setting, which enables you to maintain a steady temperature in your residence.


Target temperature for incoming water (in °C)



4.2.3.3 - Target temperature in 'Eco' mode

Parametre *PAR213* is used to adjust the heating curve in Eco mode so that the temperature is lower than in Comfort mode.


Target temperature for incoming water (in °C)



4.2.3.4 - Target temperature in Frost Protection mode

Parametre *PAR214* is used to adjust the heating curve in Frost Protection (FP) mode so that the temperature is lower than in Comfort mode.


Target temperature for incoming water (in °C)




4.2.3.5 - Resetting installer parametres 205 to 230

Accessing the Installer Menu:

- Press 
- Turn the dial until the screen displays "INST. MENU"
- Press  and  **at the same time**
- **Keep them held down simultaneously** for 3 sec.



Press  to return to "INST. MENU" screen.

- Press "YES" to stop the installation.

4.2.3.6 - Selecting the HRC⁷⁰ Heat Pump heating capacity




The Heat Pump can run using only 1 compressor: the small one (compressor 1) or the large one (compressor 2). This function is only useful in case of repair work being done and must be used only on a temporary basis.


- PAR.230 = 0 : default setting - normal operation
- PAR.230 = 1 : compressor 1 only operating
- PAR.230 = 2 : compressor 2 only operating


4.2.4 - FORCED COMMAND of the system

In order to diagnose errors occurring on Heat Pump components, certain elements can be manually engaged on a temporary basis.

Accessing the Installer Menu:

- Press 
- Turn the dial until the screen displays "INST. MENU"
- Press  and  **at the same time**
- **Keep them held down simultaneously** for 3 sec.






5 - USE

5.1 - Setting the date and time

Setting the date and time enables the system to automatically adapt to different heating modes. See § "Setting heating modes".

• Press "Clock settings"



• Press  to return to main screen.




N.B: When the display is left inactive for a few minutes, it will revert to the normal display and backlighting will switch off

5.2 - Displaying the control values

To access the control data, such as pressure readings (in bars) and all the temperatures read by the sensors (in °C), press and hold down the dial for 3 seconds. While the dial is pressed down, "DISPLAY" will appear on the screen.

- Turn the dial to the right to scroll through the display options (the values given below are examples):



i **N.B:** Temperature display
If 2 heating zones are set, the temperature is displayed for each zone

example
AMBIENCE 1
19.0°C

i **N.B:** =If the heating zones are controlled by a thermostat rather than a room temperature sensor, the display will show: (heating request = 1 ; comfort mode= 0)

example
AMBIENCE 1
1



N.B: The screen only displays information for the DHW sensor if it has been set up. See § "Installer menu / Configuration"

example
DHW SENSO.
53°C

example



N.B: If the DHW zone is controlled by an aquastat (heating request = 1 ; comfort mode = 0)

example
AQUASTAT
0

example

- Press on the dial or the key to return to the main screen.



N.B: If the swimming pool kit is connected and activated, both the temperature and the flow rate (no flow rate detected = 0; flow rate detected = 1) will be automatically displayed.

example
SWIM. POOL
23.5°C

example

example
POOL FLOW
1


example


- Press on the dial or the key to return to the main screen.

5.3 - User Menu

The User Menu allows you to access the settings for heating modes, operating and stopping the appliance, and also to view the temperatures in the installation.

- Press to access the User Menu.






i **N.B:** When the circuit(s) are controlled by a thermostat (ou aquastat for domestic hot water), the *SETTING* sub-menu will not appear.

5.3.1 - Setting target temperatures


i **N.B:** When 2 circuits are used for heating and each one has a room temperature sensor, the *SETTING* sub-menu offers the following options:
AMBIENCE 1 AMBIENCE 2 ECO 1 ECO 2 ANTI FREEZ 1 ANTI FREEZ 2



N.B: The temperature sensor is connected and the parametres set.


5.3.1.1 - Setting the *AMBIENCE* target temperature

N.B: Only when there is a room temperature sensor and display on circuit 1.




5.3.1.2 - Setting the *ECO* target temperature

N.B: Only when there is a room temperature sensor and a display




5.3.1.3 - Setting the *ANTI FREEZ* target temperature

N.B: Only where there is a room temperature sensor and display




5.3.1.4 - Setting the domestic hot water temperature

Nota: Only for producing domestic hot water and when there is a domestic water temperature sensor.



5.3.1.5 - Setting the SWIM. POOL temperature


N.B: Only where there is a swimming pool.



• Press to return to main screen.

5.3.2 - Setting a VACATION period

The "VACATION" function enables you to put the appliance and the whole installation on standby whilst keeping the frost protection function active (water maintained at 11°C). This function can be programmed to run for between 1 and 99 days. It is effective as soon as the number of days has been validated.




The number of days left on the display will decrease every day. "VACATION" mode will end automatically at the end of the programmed time period. The time period can be modified or stopped (through the User Menu) while holiday mode is in progress.

• Press to return to the main screen, which will be showing:

HOLI. RETUR.
15 D


5.3.3 - Temporary **OVERRIDE** of the programmed heating mode

The programmed heating mode can be overridden, for example if you are home in a time period where the residence is usually empty and you require heating.




OVERRIDE

N.B: • If the heating mode is overridden, it will apply to all circuits which are running
• The override will end when the next programmed cycle in the same heating mode starts up



5.3.4 - **BOOST** function

The **BOOST** function temporarily forces the operation of the Heat Pump and the electrical back-up or boiler back-up (if the latter is authorised) to speed up the rise in temperature during a heating cycle. It is automatically deactivated as soon as the heating curve target temperature is reached.




• Press to return to the main screen, which will display

BOOST
34°C

5.3.5 - Selecting SUMMER / WINTER mode

The SUMMER / WINTER mode enables you to switch modes manually:




• Press to return to main screen.

5.3.6 - Selecting the LANGUAGE

See § "Appliance configuration / Language".

5.3.7 - BEEP alert

• This menu is for choosing a sound alert for each press of the dial.



example

5.3.8 - Accessing the INST. MENU

• Press then and keep them held down simultaneously for 3 seconds to access the installer menu.

N.B: See § "Appliance Configuration / Installer Menu"

INST. MENU

6 - MAINTENANCE AND REPAIRS



• In order to ensure the best performances from your HRC⁷⁰ Heat Pump it should be maintained.

- An annual maintenance check is recommended on the hydraulic heating circuit, to be carried out by a qualified professional.
- Any work undertaken on the refrigerant circuit **MUST** be carried out by a qualified professional with a category 1 certificate of aptitude
- Switch the appliance off before opening it

6.1 - General information

After the appliance has been running for a few days, it is advisable to check that the water circuit is watertight and that condensates are draining correctly.

N.B: In case of maintenance work or decommissioning an appliance, please respect all environmental protection instructions concerning recovery, recycling and disposal of consumables and components.

6.2 - Hydraulic circuit maintenance

6.2.1 - Water circuit condensate drainage

Checking the water circuit consists of removing sludge, checking the filters and stopping up any leaks that may have appeared. Clean or replace clogged or dirty filters.


Check from time to time that the condensates are draining properly:

- Remove the back panel
- Check the drainage hole for blockages
- Clean the condensates collection trough as deposits from air intake may accumulate here.
- Clean the flexible drainage hose

Case a : drainage from underneath

Cas b : drainage from the back

Check that the pressure relief valve is properly sealed. It should not leak if the water pressure is under 2.5 bars.



6.2.2 - HRC⁷⁰ Pilot

We would advise you to have an annual maintenance check carried out on the HRC⁷⁰ Pilot, which should be done by a qualified professional.

- When operating with electrical back-up, after the appliance has been running for a few days and then at least once a year, all the electrical power connections (switches and heating elements) should be checked to ensure that they are properly tightened.
- Briefly activate the sludge valve and check the water pressure (use back-up if necessary)
- Clean the valve filter

6.2.3 - Heating circuit maintenance

- Release any trapped air in the HRC⁷⁰ Pilot.
- Check that the whole circuit is watertight, as well as the pressure relief valves.
- Check the hydraulic pressure. This should not be any higher than the water pressure in the expansion vessel. It should never be higher than 2.5 bars when hot. If the water pressure is low, check that all of the circuitry is watertight before adding more water.
- Check the composition and condition of the water in the heating circuit.
- Check the hydraulic circuit, cleaning the filter and checking the water quality (pH level, anti-freeze, etc.).

6.3 - Heat Pump maintenance

The HRC⁷⁰ Heat Pump contains type R290 refrigerant. This means that it is not subject to the regulations on the greenhouse effect and does not require an annual maintenance check by a qualified professional.

However, we would recommend that from time to time (at least once a year) the evaporator fins are cleaned if they have collected leaves or dust on them. This should be done by using a vacuum cleaner or spraying them with water.



Never clean the finned heat exchanger with high-pressure cleaning equipment: this could damage the fins.

In case of repair work on the HRC⁷⁰ Heat Pump, the refrigerant circuit or the electrical box, it is important to follow the instructions below:

Any work on the refrigerant circuit must be undertaken by a qualified professional with a category 1 certificate of aptitude. It is forbidden to release gas from the refrigerant into the atmosphere and it is obligatory to recover the refrigerant before doing any work on the circuit.

The HRC⁷⁰ Heat Pump uses a type R290 refrigerant. Given the flammable nature of this fluid, any work on the refrigerant circuit must be carried out using suitable equipment which complies with the current rules and regulations. When handling the fluid (recovery, draining or refilling), the machine must be disconnected from the power supply. Do not smoke or light flames (lighter, blow-torch) when handling the fluid. If it is necessary to work on the refrigerant circuit using a flame (a blow-torch) the refrigerant circuit must be drained and emptied beforehand and a nitrogen vacuum must be created.

6.4 - Electrical components maintenance




- **Always disconnect the appliance from the power supply before accessing electrical terminals.**
- **Do not put water on any electrical parts.**



- Check on both the HRC⁷⁰ Heat Pump and HRC⁷⁰ Pilot that the electrical power supply cables are connected properly on the terminals.
- Check for oxidation or overheated areas on the electrical connections.
- Check that the cables are well-tightened on the compressor starters.
- Clean any dust from the electrical box and check the connections.
- Check that the ground cable is properly connected.

6.5 - Checking operating temperatures

6.5.1 - Accessing control readings and internal / external controls

Check the values read by the HRC⁷⁰ Heat Pump







6.5.2 - Accessing calculated data

Accessing the Installer Menu:


- Press 
- Turn the dial until the screen displays "INST. MENU"
- Press  and  **at the same time**
- **Keep them held down simultaneously** for 3 sec.





• Press at any time to return to the *DATA CALC.* screen.


N.B: If 2 circuits are configured, the heating curve is displayed for each circuit



6.5.3 - Accessing the meters

Accessing the Installer Menu:

- Press
- Turn the dial until the screen displays "INST. MENU"
- Press and **at the same time**
- **Keep them held down simultaneously** for 3 sec.



Meter	Function	Unit
1	Zone 1 heating request	hour
2	Zone 2 heating request	hour
3	Heating request for zone 1 as pool	hour
4	Heat pump operation (at least 1 power stage functioning)	hour
7	Compressor 1 operation	hour
8	Compressor 2 operation	hour
9	Boiler back-up request	hour
10	Electrical back-up operation stage 1	hour
11	Electrical back-up operation stage 2	hour
12	Electrical back-up operation stage 3	hour
13	De-icing cycles	number

6.6 - Errors which are not signalled by error message or alert

Error not displayed on screen	Possible causes	Solutions
The heat pump will not start	<ul style="list-style-type: none"> •The installation is in summer mode •The room thermostat is not sending a heating request 	<ul style="list-style-type: none"> •Check values of <i>PAR.209 AND 215</i> and switch to winter mode then auto •Check the room thermostat is connected properly to the power supply and the pilot •Check that the room thermostat is configured correctly
	<ul style="list-style-type: none"> • There is no voltage at the appliance's terminals 	<ul style="list-style-type: none"> •Check the power supply throughout the heat pump (check there is voltage and the values: compressor start-up is prevented if voltage is too high or too low)
	<ul style="list-style-type: none"> •The circuit breaker cuts the power off at each start-up 	<ul style="list-style-type: none"> •The nominal current is insufficient for the circuit breaker •Check the ground insulation on the compressors, the fan and other electrical components (eg. the circulator pump) •The circuit breaker used on the heat pump will not allow a motor start-up: install a D-curve circuit breaker •One of the heat pump electrical components is defective
The heat pump will start up but does not produce enough heat	<ul style="list-style-type: none"> •The heat pump is too small to meet heating requirements 	<ul style="list-style-type: none"> •Check that all the start-up stages of the heat pump engage properly •Check the PT/OP and LS cables and <i>PAR.217</i> and <i>218</i> •Check that heat pump back-up engages properly: it must be properly configured. •No check valve on boiler •Check that electrical back-up is enabled •Check the value of the outdoor temperature sensor reading
	<ul style="list-style-type: none"> • Compressor(s) not working 	<ul style="list-style-type: none"> •Check the status of the progressive starters •Check the three phase cabling
	<ul style="list-style-type: none"> •The compressor has been stopped by its internal thermal safety device 	<ul style="list-style-type: none"> •Check that operating conditions are within the authorised range
The heat pump is heavily blocked by ice	<ul style="list-style-type: none"> •Condensates drainage is blocked •The air temperature sensor is giving an incorrect reading •The de-icing sensor is giving an incorrect reading 	<ul style="list-style-type: none"> •Melt the ice by forcing de-icing with hot water and stopping the heat pump (do not use tools to break or unstick the ice) •Check that the outside air temperature and de-icing sensors are correctly positioned and reading the temperatures properly •Fit a heater cable (available as an accessory) for condensates drainage

6.7 - Compressor start-up faults

GREEN light	RED light	Possible causes	Solutions
On	-	Running normally	-
Flashing	-	• Insufficient voltage	• Check the power supply voltage on the heat pump: it must be over 200 volts (minimum)
	2 flashes	• Abnormal drop in voltage during start-up	• Insufficient power grid voltage • Check the compliance of the power supply from the general meter to the heat pump • Contact your electricity provider to ensure that power grid sizing is adapted
	3 flashes	• Over-current at start-up	• Contact an AUER-approved technical centre
	4 flashes	• Internal starter defect	• Replace starter
	5 flashes	• Start-up process incomplete	• Check the power supply to the heat pump <u>before</u> and <u>during</u> start-up. It must not drop below 200 volts

Three-phased started for the HRC⁷⁰ 25kW three phase heat pump


	Alert signal	Possible causes	Solutions
	2 flashes	• Phases are inversed	• Inverse 2 phases on the power supply of the starter
	3 flashes	• Power supply voltage outside authorised range	• Check the voltage on the three phased network • Check the compliance of the power supply from the general meter to the heat pump • Contact your electricity provider to ensure that power grid sizing is correct
	4 flashes	• Non-compliant power supply frequency	• Contact an AUER-approved technical centre • Contact your electricity provider
	5 flashes	• Compressor blocked	• Contact an AUER-approved technical centre
	6 flashes	• Start-up process incomplete	• Check the power supply to the heat pump <u>before</u> and <u>during</u> start-up. It must not drop below 350 volts
	7 flashes	• Starter overheating	• Contact an AUER-approved technical centre
	8 flashes	• Over-current at start-up	• Contact an AUER-approved technical centre
	9 flashes	• Imbalance of phases	• Check voltage on the three phased network • Check the compliance of the power supply from the general meter to the heat pump • Contact your electricity provider

6.8 - Alerts and errors which are signalled by the appliance

Faults are signalled by the back-lighting flashing and a sound signal.

Press the dial to stop the sound signal. The alarm will stop but the error will still be displayed.

If it is an automatic reset fault, the signal will disappear once the problem has been rectified.

If it is a manual reset fault, rectify the problem and then press on the dial to make the signal disappear. Manual reset faults are indicated with the following symbol: 

N.B: The swimming pool sensor error is only signalled when the ohmic value is too low. The absence of a swimming pool sensor does not generate a fault because it either means that there is no swimming pool or that the swimming pool function has been deactivated.

To view the list of errors and find out how to rectify them, please refer to: "Operating errors" and "Error message codes".

6.9 - Error messages

6.9.1 - Errors and solutions


Display	Nature of error	Solutions
<i>AIR HP</i> <i>ERR</i>	Heat pump air temperature sensor defect	<ul style="list-style-type: none"> • check that the HP air temperature sensor is correctly connected to the HP electronic circuit board • check the coupler plug on the HP air temperature sensor • check the ohmic value of the sensor • replace the HP air temperature sensor
<i>EVAPD</i> <i>ERR</i>	De-icing sensor defect	<ul style="list-style-type: none"> • check that the de-icing sensor is correctly connected to the HP electronic circuit board • check the de-icing sensor cable • check the ohmic value of the sensor • replace the de-icing sensor
<i>AMBIENCE</i> <i>ERR</i>	Room temperature sensor defect	<ul style="list-style-type: none"> • check that the room temperature sensor is correctly connected to the HP electronic circuit board • check the room temperature sensor cable • check the ohmic value of the sensor • replace the room temperature sensor
<i>AMBIENCE 1</i> <i>ERR</i>	Room temperature sensor 1 defect	<ul style="list-style-type: none"> • check that room temperature sensor 1 is correctly connected to the HRC Pilot electronic circuit board • check the room temperature sensor 1 cable • check the ohmic value of the sensor • replace room temperature sensor 1
<i>AMBIENCE 2</i> <i>ERR</i>	Room temperature sensor 2 defect	<ul style="list-style-type: none"> • check that room temperature sensor 1 is correctly connected to the HRC Pilot electronic circuit board • check the room temperature sensor 2 cable • check the ohmic value of the sensor • replace room temperature sensor 2
<i>BUS</i> <i>ERR</i>	Bus wire link defect	<ul style="list-style-type: none"> • check that the HP is connected to the power supply • check that the bus wire is correctly connected to the HRC Pilot electronic circuit board (2 wires) without the ground. • check that the bus wire is correctly connected to the HP electronic circuit board (2 wires) without the ground. • three phased HP connected with 2 phases inversed • check the phase monitor (orange and green lights should be on) • check the condition of the 4A fuse on the outer unit
<i>COMPRES-1</i> <i>ERR</i>	Compressor 1 sensor defect	<ul style="list-style-type: none"> • check that compressor sensor 1 is correctly connected to the HP electronic circuit board • check the compressor 1 cable • check the ohmic value of the sensor • replace compressor sensor 1
<i>COMPRES-2</i> <i>ERR</i>	Compressor 2 sensor defect	<ul style="list-style-type: none"> • check that compressor sensor 2 is correctly connected to the HP electronic circuit board • check the compressor 1 cable • check the ohmic value of the sensor • replace compressor sensor 1
<i>FLOW</i> <i>ERR</i>	Insufficient water flow rate or Absence of flow rate	<ul style="list-style-type: none"> • check that the circulator pump is working properly (manual forced command) • check that there is voltage at the circulator pump terminal (qualified professionals only) • clean the filter valve • clean the circulator pump if necessary • check that the check valve is fitted the right way up
<i>LOW FLOW</i> <i>ERR</i>	Low water flow rate	<ul style="list-style-type: none"> • switch the circulator pump to speed 3 • clean the filter valve • check that the length and diameter of the piping is suitable • check that the capacitor input is not clogged
<i>FLOW DETEC</i> <i>ERR</i>	Flow rate monitor malfunction	<ul style="list-style-type: none"> • check the wiring of the flow rate monitor on the HRC Pilot electronic circuit board • check that the flow rate monitor vane is not stuck • check that the flow rate monitor has not been shunted
<i>FREQ. DEFRO.</i> <i>ERR</i>	De-icing too often	<ul style="list-style-type: none"> • check that the fan is working properly • check the condition of the heat exchanger • check that the heat pump air sensor and evaporator sensor are working properly • Evaporation pressure too low: Intervention needed on refrigerant circuit
<i>LONG DEFRO.</i> <i>ERR</i>	De-icing phase too long	<ul style="list-style-type: none"> • check that the fan is working properly • check the condition of the heat exchanger • check that the heat pump air sensor and evaporator sensor are working properly • check that the 4-way valve is working properly by a qualified professional
<i>OUTSIDE</i> <i>ERR</i>	Outdoor temperature sensor defect	<ul style="list-style-type: none"> • check that the outdoor temperature sensor 1 is correctly connected to the HRC Pilot electronic circuit board • check the outdoor temperature sensor cable • check the ohmic value of the sensor • replace the outdoor temperature sensor
<i>CLOCK</i> <i>ERR</i>	Clock / timer defect	<ul style="list-style-type: none"> • 1 - Press the clock key and set the date and the time • 2 -If the fault persists, replace HRC Pilot electronic circuit board
<i>MEMORY</i> <i>ERR</i>	Memory card defect	<ul style="list-style-type: none"> • replace HRC Pilot electronic circuit board
<i>MODULE</i> <i>96°C</i>	Outgoing heating water overheating defect > 80°C Temperature read is displayed	<ul style="list-style-type: none"> • check the electrical back-up power relay system is functioning properly • check that the flow rate is sufficient from the back-up boiler • check the command status of the back-up boiler • check that the heating circulator pump is working properly
<i>MODULE</i> <i>ERR</i>	HRC Pilot outgoing water sensor defect	<ul style="list-style-type: none"> • check that the Pilot outgoing water sensor is correctly connected to the HRC Pilot electronic circuit board • check the HRC Pilot outgoing water sensor cable • check the ohmic value of the HRC Pilot outgoing water sensor • replace the HRC Pilot outgoing water sensor

Display	Nature of error	Solutions
HP OUTPUT 76.2°C	HP outgoing water overheating defect > 75°C Temperature read is displayed	<ul style="list-style-type: none"> • check condition of filter valve: clean filter • check that HP flow rate is sufficient • check that heating circulator pump is operating correctly
HP OUTPUT ERR	HP outgoing water sensor defect	<ul style="list-style-type: none"> • check that the HP outgoing water sensor is correctly connected to the heat pump electronic circuit board • check the HP outgoing water sensor cable • check the ohmic value of the heat pump outgoing water sensor • replace the heat pump outgoing water sensor
HP INPUT ERR	HP incoming water sensor defect	<ul style="list-style-type: none"> • check that the HP incoming water sensor is correctly connected to the heat pump electronic circuit board • check the HP incoming water sensor cable • check the ohmic value of the heat pump incoming water sensor • replace the heat pump incoming water sensor
EVAP. SENSO. ERR	Evaporator sensor malfunctioning	<ul style="list-style-type: none"> • check the heat pump air temperature sensor and evaporator sensor are operating correctly • check that the 4way valve is operating correctly • check that the compressor starter is not faulty • check that the evaporator sensor is not covered in ice
PROB COMP1	Compressor 1 power supply fault	<ul style="list-style-type: none"> • check that power grid is adapted to the heat pump's electricity requirements • check that the power supply voltage does not drop below 200W during start-ups • check for errors on compressor 1 starter (see § "Compressor start-up errors") • check power supply voltage • check power connections from electrical box to compressor 1 terminals • check compressor 1 discharge sensor
PROB COMP2	Compressor 2 power supply fault	<ul style="list-style-type: none"> • check that power grid is adapted to the heat pump's electricity requirements • check that the power supply voltage does not drop below 200W during start-ups • check for errors on compressor 1 starter (see § "Compressor start-up errors") • check power supply voltage • check power connections from electrical box to compressor 2 terminals • check compressor 2 discharge sensor
STARTER 1 ERR	Smart starter 1 error	<ul style="list-style-type: none"> • check that power grid is adapted to the heat pump's electricity requirements • check that the power supply voltage does not drop below 200W during start-ups • check for errors on compressor 1 starter (see § "Compressor start-up errors") • check power supply voltage • check power connections from electrical box to compressor 1 terminals
STARTER 2 ERR	Smart starter 2 error	<ul style="list-style-type: none"> • check that power grid is adapted to the heat pump's electricity requirements • check that the power supply voltage does not drop below 200W during start-ups • check for errors on compressor 1 starter (see § "Compressor start-up errors") • check power supply voltage • check power connections from electrical box to compressor 2 terminals
SWIM POOL ERR	Swimming pool sensor defect	<ul style="list-style-type: none"> • check that the swimming pool sensor is correctly connected to the HRC Pilot electronic circuit board • check the swimming pool sensor cable • check the ohmic value of the swimming pool sensor • replace swimming pool sensor
OUT SENSO. ERR	Outdoor temperature reading defective Outdoor sensor and HP air temperature sensor show very different values	<ul style="list-style-type: none"> • check position of outdoor sensor • check values on both sensors (outdoor and HP air temp.) → if one of the sensors is giving an erroneous reading, check condition of sensor • check condition of cable and connections for each sensor • replace defective sensor
PRESSURE 0.2	Insufficient water pressure	<ul style="list-style-type: none"> • the water pressure in the heating circuit must be over 0.5 bars when cold. • check that the heating circuit is watertight and repair any leaks. • purge the air from the uppermost parts of the installation and the HRC Pilot. • check that the heat pump pressure relief valve is watertight. • check that the HRC Pilot pressure relief valve is watertight. • check that the expansion vessel is big enough for the volume of the installation
CUTO. LPRE	HP low pressure	<ul style="list-style-type: none"> • check that the fan is operating correctly (capacitor and electrical connections). • check the condition of the finned heat exchanger surface and remove anything which could be hampering the airflow through the rear grille (eg. leaves) • if completely iced over, switch off the heat pump and let the ice melt. Spray with hot water if necessary. • refrigerant leak, de-icing valve blocked or pressure reducing valve defect by a qualified professional
CUTO. HPRE 1	HP high pressure error compressor 1	<ul style="list-style-type: none"> • check condition of filter valve • check that heating network is properly purged • check that HP circulator pump is running properly • clean plated heat exchanger inlet • discharge valve or 4-way valve malfunction
CUTO. HPRE 2	HP high pressure error compressor 2	<ul style="list-style-type: none"> • check condition of filter valve • check that heating network is properly purged • check that HP circulator pump is running properly • clean plated heat exchanger inlet • discharge valve or 4-way valve malfunction
DHW TEMP ERR	Swimming pool sensor defect	<ul style="list-style-type: none"> • check that the DHW sensor is correctly connected to the HRC Pilot electronic circuit board • check the DHW sensor cable • check the ohmic value of the DHW sensor • replace DHW sensor

6.9.2 - Operating in case of error

When an error occurs the backlighting flashes.

Any defect which stops the appliance from operating is indicated by an alarm .

When the error needs to be manually rectified the  symbol is displayed.




Display	Name	Source of defect	Consequence(s)	Repair & removing error message
AIR HP ERR	Air temperature sensor defect	HP air temp. sensor data is illogical	Target temperature = (max.water temp.+ min. water temp) / 2	Automatic after repair
AMBIENCE 1 ERR	Amb1 sensor defect	Attention : the room temperature sensor with display should be entered as INT SENSOR for circuit 1 only • Room temperature control for circuit 1 is programmed in just as SENSOR and the data received is illogical or • It is not, so the swimming pool sensor is recognised and the data received is illogical	Heating request	Automatic after repair
AMBIENCE 2 ERR	Amb 2 sensor defect	Attention : the room temperature sensor with display should be entered as INT SENSOR for circuit 1 only Circuit 2 is programmed as a radiator or underfloor heating circuit with room temperature sensor and the data received is illogical	Heating request	Automatic after repair
BUS ERR	BUS	2-core sheathed cable or BUS connector defect or fuse not working or electronics board(s) defect	HP stopped, back-up only authorised	BUS link or replacement fuse or replacement of electronics board / Manual
COMPRES-1 ERR	Compressor 1 sensor defect	Compressor 1 sensor data is illogical	Both compressors stop and also the fan	Automatic after repair
	Compressor 1 temperature defect	Compressor 1 overheating (compressor temperature>115°C) more than 24 times in 24 hours	Both compressors stop	Manual
COMPRES-2 ERR	Compressor 2 sensor defect	Compressor 2 sensor data is illogical	Both compressors stop and also the fan	Automatic after repair
	Compressor 2 temperature defect	Compressor 1 overheating (compressor temperature>115°C) more than 24 times in 24 hours	Both compressors stop	Manual
FLOW ERR	Zero flow rate defect	"Zero flow rate" repeated after 8 attempts	HP stopped	Manual
LOW FLOW	Insufficient flow rate error	Difference in temperature too large between heat pump inlet and outlet	Normal operation	Manual
FLOW DETEC. ERR	Flow rate detector defect	Flow rate inlet = 1 and Heat pump CP outlet = 0	No HP start-up = heat pump off and back-up on (if authorised)	Automatic as soon as flow rate = 0 and HPCP = 0
	Zero flow rate error	Flow rate inlet = 0 HP circulator pump = 1	No HP start-up	Automatic with Hp circulator pump attempts = 1 every 2 minutes
FREQ. DEFRO ERR	De-icing too often	De-ices more than three times per hour	HP stopped, only electrical back-up runs (if authorised)	Manual

Display	Name	Source of defect	Consequence(s)	Repair & removing error message
<i>EVAPD ERR</i>	De-icing sensor error	De-icing sensor data is illogical	Heat pump stopped, electrical back-up only authorised	Automatic after repair
<i>OUTSIDE ERR</i>	Outdoor sensor defect	Outdoor sensor data is illogical	HP air temperature replaces outside temperature if outdoor sensor is unplugged	Automatic after repair
<i>CLOCK ERR</i>	Clock / timer	1 - clock not set 2 - PCB fault	Permanently operates in eco mode (heating modes ignored)	Replace electronics board Manual
<i>MEMORY ERR</i>	Memory	Memory defect	HP stopped and backup stopped	Replace electronics board Manual
<i>MODULE 96°C</i>	Overheating at HRC Pilot outlet	"Module outlet overheating error" repeated more than 12 times in 24h	Both compressors and back-up stopped	Manual
	Overheating at HRC Pilot outlet	Outgoing water temp. > 80°C	Compressor and back-up stop briefly	Automatic as soon as outgoing water temp < 80 – 10°C
<i>HP OUTPUT ERR</i>	HP outgoing water temp sensor defect	HP outgoing water temp. sensor data is illogical	HP stopped, back-up only authorised	Automatic after repair
<i>HP OUTPUT 76.2°C</i>	Overheating defect at HP outlet	"HP outlet overheating error" repeated more than 10 times in 24h	Both compressors and back-up stopped	Manual
	Overheating error at HP water outlet	HP outgoing water temp > 75°C	Compressor and back-up stop briefly	Automatic as soon as outgoing water temp. < 75 – 10°C
<i>HP INPUT ERR</i>	HP incoming water temp. sensor	HP incoming water temp. sensor data is illogical	HP stopped, back-up only authorised	Automatic after repair
<i>PROB COMP1</i>	Compressor 1 power supply defect	Problems at start-up, power grid not suitable, insufficient voltage, progressive start-up defective	Compressor 1 stopped. Heat pump attempts compressor start-up every hour.	Manual after normal operation has resumed
<i>PROB COMP2</i>	Compressor 2 power supply defect	Problems at start-up, power grid not suitable, insufficient voltage, progressive start-up defective	Compressor 2 stopped. Heat pump attempts compressor start-up every hour.	Manual after normal operation has resumed
<i>STARTER 1 ERR</i>	Smart starter 1 error	Problems at start-up, power grid not suitable, insufficient voltage, progressive start-up defective	Compressor 1 stopped. Heat pump attempts compressor start-up every 20 minutes	Manual
<i>STARTER 2 ERR</i>	Smart starter 2 error	Problems at start-up, power grid not suitable, insufficient voltage, progressive start-up defective	Compressor 2 stopped. Heat pump attempts compressor start-up every 20 minutes	Manual
<i>EVAP. SENSO</i>	Evaporator sensor data illogical	The values read by the air and evaporator sensors are illogical while a compressor is running.	Defect displayed, heat pump still operational	Manual after normal operation has resumed
<i>PILOT ERR</i>	Outgoing water temp. sensor defect	Outgoing water temp. sensor data is illogical	Backup stopped	Automatic after repair
<i>SWIM. POOL ERR</i>	Swimming pool sensor defect	Ohmic value of swimming pool sensor is too low	No heating request for swimming pool	Automatic after repair
<i>OUT SENSO ERR</i>	Outdoor sensor positioning error	Air temp. – Out. > 15K or Out – Air temp. > 15K	Temperature for heating curve = (Air temp. + Out.)/2	Automatic
<i>PRESSURE ERR</i>	Pressure sensor defect	Pressure detector disconnected or defective	HP and back-up stopped	Automatic after repair
<i>PRESSURE 0.2</i>	Insufficient water pressure	Pressure measured by pressure sensor < 0.3 bar	Both compressors stopped and back-up and circulator pumps after 2 min.	Automatic as soon as pressure > 0.5 bar

Display	Name	Source of defect	Consequence(s)	Repair & removing error message
<i>CUTO. HPRE1</i>	HP1 cutout	HP1 pressure switch on	Both compressors stopped	Manual
<i>CUTO. HPRE2</i>	HP2 cutout	HP2 pressure switch on	Both compressors stopped	Manual
<i>CUTO. LPRE</i>	Low pressure error	LP pressure switch on	Both compressors stopped	Automatic when low pressure switch off Manual after 3 errors in the same hour
<i>DHW TEMP. ERR</i>	DHW temp. sensor error (Amb2 input on electronics board)	Circuit 2 is programmed as domestic water circuit with DHW sensor and the data readings from this sensor are illogical	No domestic hot water request	Automatic after repair

6.10 - Sensor data curve charts

6.10.1 - Water inlet and outlet HRC⁷⁰ Heat Pump and HRC⁷⁰ Pilot De-icing sensor - Air intake sensor - Sensors fitted to compressors 1 and 2 - Swimming pool sensor - DHW sensor



Temp. (°C)	Sensor value (KOhms)	Temp. (°C)	Sensor value (KOhms)	Temp. (°C)	Sensor value (KOhms)	Temp. (°C)	Sensor value (KOhms)
-40	351.078	10	20.017	60	2.472	110	0.504
-35	251.277	15	15.768	65	2.068	115	0.439
-30	182.451	20	12.513	70	1.739	120	0.384
-25	133.827	25	10.000	75	1.469	125	0.336
-20	99.221	30	8.045	80	1.246	130	0.296
-15	74.316	35	6.514	85	1.061	135	0.261
-10	56.202	40	5.306	90	0.908	140	0.231
-5	42.894	45	4.348	95	0.779	145	0.204
0	33.024	50	3.583	100	0.672		
5	25.607	55	2.968	105	0.581		

6.10.2 - Outdoor sensor

Temp. (°C)	Resist. R (KOhms)	Temp. (°C)	Resist. (KOhms)	Temp. (°C)	Resist. (KOhms)	Temp. (°C)	Resist. (KOhms)
-30	171 800	-11	61 930	8	24 947	27	11 079
-29	161 817	-10	58 880	9	23 853	28	10 645
-28	152 994	-9	56 004	10	22 800	29	10 231
-27	144 697	-8	53 280	11	21 819	30	9 804
-26	136 894	-7	50 702	12	20 879	31	9 460
-25	129 800	-6	48 263	13	19 986	32	9 101
-24	122 646	-5	45 950	14	19 137	33	8 759
-23	116 145	-4	43 769	15	18 300	34	8 434
-22	110 025	-3	41 699	16	17 565	35	8 054
-21	104 261	-2	39 739	17	16 839	36	7 749
-20	98 930	-1	37 881	18	16 151	37	7 456
-19	93 713	0	36 130	19	15 500	38	7 176
-18	88 888	1	34 453	20	14 770	39	6 909
-17	84 339	2	32 871	21	14 168	40	6 652
-16	80 047	3	31 371	22	13 590	41	6 408
-15	76 020	4	29 948	23	13 039	42	6 173
-14	72 174	5	28 600	24	12 514	43	5 947
-13	68 564	6	27 317	25	12 000	44	5 731
-12	65 153	7	26 101	26	11 535	45	5 522

6.11 - Decommissioning and disposal


In accordance with current laws, no equipment must be disposed of without the refrigerant gas, recyclable metallic parts and the oil contained in the compressors having been recovered beforehand.

NOTES / MAINTENANCE

[illegible]

7 - PARTS


7.1 -HRC⁷⁰ Heat Pump




Number	References				Product
	HRC ⁷⁰ heat pump model				
	17 kW Single phase	17 kW Three phase	20 kW Single phase	25 kW Three phase	
1	4992030	4992032	4992034	4992035	Compressor 1
2	4992031	4992033	4992031	4992036	Compressor 2
3	1472698	1472698	1472728	1472728	Plate-type condenser
4	1472653	1472653	1472653	1472684	Evaporator
5	1472696	1472696	1472696	1472696	Dehydrating filter
6	1472690	1472690	1472702	1472702	Suction accumulator
7	1472692	1472692	1472719	1472719	4-way valve
8	1472693	1472693	1472718	1472718	Thermostatic expansion valve
9	1472691	1472691	1472691	1472691	Compressor 1 check valve
10	1472691	1472691	1472691	1472700	Compressor 2 check valve
11	1472711	1472711	1472711	1472711	Steam injection valve
12	1239169	1239169	1239169	1239169	High pressure switch
13	1239170	1239170	1239170	1239170	Low pressure switch
14	1243955	1243955	1243955	1243955	Water inlet temperature sensor
15	1243955	1243955	1243955	1243955	Water outlet temperature sensor
16	1243955	1243955	1243955	1243955	De-icing sensor
17	1243955	1243955	1243955	1243955	Outdoor temperature sensor
18	1243955	1243955	1243955	1243955	Compressor 1 temperature sensor
19	1243955	1243955	1243955	1243955	Compressor 2 temperature sensor
20	1472730	1472730	1472730	1472730	HP pressure tap
21	1472730	1472730	1472730	1472730	LP pressure tap
22	1591385	1591385	1591385	1591385	Fan set
23	1239128	1239128	1239128	1239128	2.5 bar safety valve
24	4948083	4948083	4948083	4948083	Condensate drainage pipe
25	1243963	1243963	1243963	1243963	Compressor 1 heating belt
26	1243963	1243963	1243963	1243964	Compressor 2 heating belt

7.2 - Electrical boxes


17 kW single phase




17 kW three phase



20 kW three phase




25 kW three phase



Number	Reference	Product
1	1244040	Heat pump C4 electronics board
2	1244415	Single phase progressive starter compressor 1 & 2
3	1243959	45µF compressor capacitor
6	1244043	12µF fan capacitor
7	1244044	18µF fan capacitor
8	1243847	30A contactor
9	1244037	Three phase progressive starter
11	1243147	4A fuse
13	1943123	Phase monitor

Reference points on schematic cabling diagram		
Electrical connections to screw in	DC1	Compressor 1 starter
	DC2	Compressor 2 starter
	RCP	Phase monitor relay
	KMC1	Contactor compressor 1
	KMC2	Contactor compressor 2
	DP	Compressor 2 progressive starter
	K1 à K3	Electrical stage contactor
	BUS	2-core sheathed communication cable
Electrical connections with Faston terminals	C1	45µF compressor 1 capacitor
	C2	45µF compressor 1 capacitor
	CV1	12µF capacitor fan speed 1
	CV2	18µF capacitor fan speed 2
	K1	compressor 1
	K2	compressor 2
	AQS	110°C safety aquastat
	T	6 Kw electric immersion heater

7.3 - HRC⁷⁰ Pilot



No.	Symbol	Reference	Product
2		1243947	Electrical immersion heater
3		1243561	Contactor
4	F	4990743	Fuse holder
5		1244050	Terminal
		1244049	Single phase wiring
		1244048	Three phase wiring
6	OS	1243586	Outdoor sensor
7		1243693	HRC ⁷⁰ Pilot temperature sensor
8	SAQ	1238802	Safety aquastat
9	WP	1243661	Water pressure sensor
10	HPSV	1239094	3 bar safety valve
11	CPH	1243056	Grundfos 20-60.130 circulator pump
12	HPCP	1243662	Grundfos 20-70.130 circulator pump
13	FV	1239114	1" FF filter valve
14	C	1238970	FF 1" check valve
15	SV	1239111	3/4" valve with swivel nut
16	AP	1239089	3/8" air purge valve with rotatable nozzle
17		4484803	Side panel
18		4484990	Front panel
19		4991546	Control box
20		1239171	Flow rate monitor

8 - WARRANTY

The warranty covers the HRC⁷⁰ Heat Pump and HRC⁷⁰ Pilot components for a period of two (2) years, starting from the date the appliance was activated, if the warranty voucher was sent back to the manufacturer. In the absence of this document, the date of manufacture will be used to determine the start date.

If the appliance is commissioned by an AUER-approved technical centre you will be entitled to an extra year on your warranty: a comprehensive warranty will apply for the first year (parts, labour and on-site support) followed by two more years for parts.

The appliance is guaranteed against all manufacturing defects, provided that it was installed according to the instructions provided in this manual and in compliance with all current rules and regulations in the country of installation. All electrical connections should comply with the C15-100 standard.

Under no circumstances does a faulty part warrant the replacement of the whole appliance.

The warranty only applies to parts which we (AUER) identify as having been defective at manufacture. If necessary, the part or product should be returned to the manufacturer, but only with prior agreement from our technical department. Labour, transport and packaging costs are the responsibility of the user. Repairs on a device will not result in compensation.

The parts warranty ends at the same time as the appliance warranty. The warranty only applies to the appliance and its components and excludes any part or installation - electrical or hydraulic - external to the appliance.

The warranty will not apply where there has been no maintenance, insufficient or improper maintenance carried out on the appliance.

It is essential to carry out regular annual maintenance on your appliances and installation to ensure sustained use and durability. This maintenance should be carried out by your installer or by an **AUER**-approved technical centre. If it is not, the warranty will be null and void.

All work on the refrigerant circuit MUST be carried out by a qualified professional with a category 1 certificate of aptitude. It is forbidden to release refrigerant into the atmosphere. It is mandatory to recover the refrigerant fluid before any work is undertaken on the circuit. The HRC⁷⁰ Heat Pump uses type R290 refrigerant. Given the flammable nature of this fluid, all work must be undertaken with suitable equipment and in accordance with current regulations.

If an appliance is presumed to be the cause of any damage, it must not be moved or tampered with before an expert assessment has been carried out.

8.1 - Warranty limits

8.1.1 - General information

The warranty does not apply to defects or damage caused by situations or events such as:

- Misuse, abuse, negligence, improper transport or handling
- Incorrect installation, or installation which has been carried out without respecting the installer and user instructions

and best practice.

- Insufficient maintenance
- Modifications or changes carried out on the appliance
- Impact from foreign objects, fire, earthquakes, floods, lightning, ice, hailstones, hurricanes or any other natural catastrophe
- Movement, imbalance, collapse or settling of the ground or the structure where the appliance is installed
- Any other damage which is not due to product defects.

AUER does not guarantee against discolouration or damage sustained due to air pollution or the appliance being exposed to chemical products or bad weather conditions.

AUER products are not guaranteed against dirt, grime, stains, rust, or marks which have occurred naturally on the surface of the appliances. **AUER** is not responsible for variations in colour.

8.1.2 - Cases (non limited) for exclusion from warranty

8.1.2.1 - Heating circuit water

Cases (non limited) for exclusion from the warranty:

- Not rinsing the heating circuit
- Using rainwater or water from a well
- Not treating the water for filling the heating circuit according to the instructions in the installer instruction manual

8.1.2.2 - Handling

Cases (non limited) for exclusion from the warranty:

- Any damage sustained by impacts or falls during handling after delivery from the factory.
- Deterioration in the condition of the appliance where it has not been handled in compliance with the instructions provided in this manual.
- Deterioration in the condition of the **HRC⁷⁰ Heat Pump** because it has been leaning to the side or laid flat.

8.1.2.3 - Installation site

Cases (non limited) for exclusion from the warranty:

- Placing the **HRC⁷⁰ Pilot** in a place where it could be subject to ice or other bad weather conditions
- Lack of protection against frost and ice for the appliances and installation
- Installing the Heat Pump on ground which cannot support its weight or fitting the **HRC⁷⁰ Pilot** on a vertical surface which is not adapted to the weight of the appliance
- Not respecting a horizontal position for the Heat Pump
- Not positioning the appliances in accordance with the instructions in the installer manual.

Costs incurred due to access difficulties are not the manufacturer's responsibility.

8.1.2.4 - Electrical connections

Cases (non limited) for exclusion from the warranty:

- Faulty electrical connection which does not comply with the current national installation standards
- Not following the connection diagrams in the instruction manual
- Power supply being significantly over or under the required voltage

- Failure to comply with supply cable sections
- Absence of, or insufficient, electrical protection throughout the appliance (fuses / circuit breakers, grounding etc.)

8.1.2.5 - Hydraulic connections

Cases (non limited) for exclusion from the guarantee:

- Inversing the incoming / outgoing water connections
- Water pressure superior to 2.5 bars
- Absence of, incorrect fitting of or obstruction of pressure relief valve
- External corrosion due to piping not being correctly sealed or condensates not draining properly
- Unsuitable connections for draining and recovering condensates
- Installation which does not comply with the instructions provided in the installer manual.

8.1.2.6 - Accessories

The warranty does not cover faults or defects resulting from:

- installation of accessories which do not comply with our recommendations
- use of accessories which were not provided by us.

8.1.2.7 - Maintenance



Cases (non limited) for exclusion from the warranty:

- Not respecting maintenance instructions given in the installer manual
- Not maintaining:
 - . the evaporator
 - . the condensates drainage system
- Not using parts issued by the manufacturer
- Outer casing and bodywork being subjected to any external damage
- Abnormal sludge levels
- Not cleaning the protective filters.


APPENDICES

A1 - Dimensions

A1.1 -HRC⁷⁰ Heat Pump



A1.2 - HRC⁷⁰ Pilot



A2 - Technical data

A2.1 -HRC⁷⁰ Heat Pump

	HRC ⁷⁰ 17		HRC ⁷⁰ 20	HRC ⁷⁰ 25
	Single phase 151201	Three phase 151211	Single phase 151261	Three phase 151221
	Monobloc moulded heat pump with hydraulic connection			
Nominal heat output	16.7 kW		19.5 kW	24 kW
Heat output at +7/+35°C in normative conditions	7,2 kW		10,3 kW	10,3 kW
Power consumption at +7/+35°C in normative conditions	1,69 kW		2,5 kW	2,5 kW
COP at +7°/+35°C	4,25		4,1	4,1
Heat output at -7/+70°C	1.5 kW		13 kW	15.5 kW
Max. temperature	70°C			
R290 refrigerant	1.2 kg		1.2 kg	1.5 kg
Outdoor air temperature range	-20°C à +40°C			
Power supply	230V mono	400V tri	400V tri	400V tri
Maximum start-up current	35 A	13 A	15A	18 A
Soft starter	included	no	no	included
Main circuit breaker	40 A	16 A	16 A	20 A
Min. power cable width	3 x 10mm²	5 x 4mm²	5 x 4 mm²	5 x 6mm²
Main body	steel			
Dimensions (H x L x D)	1660mm x 1035mm x 523mm			
Weight without water	245 kg		245 kg	265 kg
Nominal water flow rate	1350 L/h		1550 L/h	1850 L/h
Hydraulic connection	26 / 34 male			
Maximum hydraulic pressure	3.1 bar			
Ø condensates drainage pipe	20 / 25 mm			
Air flow rate	3000 to 7000 m³/h			
Adjustable silent blocks	included			
Noise level Power stage 1 / 2 / 3	Noise level at 1m 50 / 54 / 58 dB(A)			

A2.2 - HRC⁷⁰ Pilot

	Single phase	Three phase
Power supply	400V three phase adaptable 230V single phase	
Decoupling tank	60 L	
Dimensions (H x L x D)	740mm x 630mm x 530mm	
Weight without water	55 kg	
Hydraulic connection	26 / 34 female	
Back-up sources	Integrated electrical	0 to 6kW three phase or single phase
	Boiler	control possible
Max. current consumption	30 A	10 A
Current protection fuse	32 A	16 A
Min. power cable diameter	3 x 6mm ²	5 x 2.5mm ²
Max. water pressure	2.5 bar	

A3 - Frost protection

In cases where the HRC⁷⁰ Heat Pump cannot run (outdoor temperature outside the operating range) if a back-up source is authorised to run (boiler or electrical) it will automatically be protected from frost and ice because the circulator pump will run and extract heat from the heating circuit, which has its temperature maintained either by the HRC⁷⁰ Pilot electrical back-up or by boiler back-up.
The water temperature remains at 5°C or over.



In all cases the piping must be properly insulated.

Underground piping should also be installed within protective guttering.

However, in case of installation without a back-up source or the Heat Pump or Pilot being switched off during the winter period (e.g: stopping accidentally, use in a second home etc...), it will be necessary to provide additional protection against frost and ice.

Apply glycol to the heating circuit (with a minimum concentration of 25% glycol) or make sure you have the hydraulic circuit draining measures in place for the HRC⁷⁰ Heat Pump and its accessories, as explained below.

Diagram for draining equipment



V1 - V2 : Draining valves
V3 - V4 - V5 : Isolating valves

Ensure that the HRC⁷⁰ Heat Pump is drained

When running normally:

- V1 - V2 and V4 are closed
- V3 and V5 are open

In case of being switched off in winter:

- V3 and V5 are closed
- V1 - V2 and V4 are open

A4 - Sizing the expansion vessel

- For an installation with radiators

The expansion vessel on the boiler may be sufficient. Check that the capacity of the existing expansion vessel corresponds to the total volume of the installation (when calculating the total volume of the installation you should take into account 60L for the HRC⁷⁰ Pilot water tank and the volume of the surge tank, if applicable).

- Sizing the expansion vessel

The volume of the expansion vessel which is required for the HRC⁷⁰ Heat Pump depends on the height of the installation. You will need to adjust the pre-charged pressure of the expansion vessel and check that the capacity is equal to the total volume of the installation:

Height of installation (m)		2.5	5	7.5	10	12.5	15
Pre-charged pressure (bars) ⁽¹⁾		0.25	0.5	0.75	1	1.25	1.5
Volume of water in installation covered by 1 litre of the expansion vessel (litres) ⁽²⁾	25% glycol	15.9	14.5	13.0	11.6	10.1	8.7
	30% glycol	15.6	14.2	12.7	11.3	9.9	8.5
	35% glycol	14.7	13.4	12.1	10.7	9.4	8.0
	40% glycol	14.0	12.7	11.4	10.2	8.9	7.6

⁽¹⁾ : Deflate and check pressure in expansion vessel if necessary

⁽²⁾ : As a guideline, take into account:

- 11 litres per kW heating capacity for steel radiators
+ 60 litres for HRC⁷⁰ Pilot
+ surge tank (if applicable)
- 13 litres per kW heating capacity for cast iron radiators
+ 60 litres for HRC⁷⁰ Pilot
+ surge tank (if applicable)
- 17 litres per kW heating capacity for underfloor heating
+ 60 litres for HRC⁷⁰ Pilot
+ surge tank (if applicable)

Or, if known, use exact volume.

Example

- Installation with 12kW cast iron radiators
- Height of installation = 10m
- Frost / ice protection with 25% glycol


Total volume of installation = 12 x 13 + 60 = 216 litres


1 litre of expansion vessel covers 11.6 litres of installation volume, so here you would need an expansion vessel with a minimum volume of 18 litres (216 / 11.6).

N.B.1: The values given here are for a radiator installation (water at 80°C). For an underfloor heating installation, multiply these values by 2.


N.B.2: The concentration of monopropylene glycol should not be less than 25%.

Accessing the heating mode setting


- Press the  key and hold down for 3 sec.

- The screen will display 


- When the symbol disappears, release the  key.

 where there are several circuits: if not, access directly on day to be programmed




Circuit 1



Circuit 2



Both circuits at the same time






A5 - Programming heating modes

Time periods with different heating modes can be programmed for each day and each circuit. The installation will automatically follow programmed heating modes. This is not recommended and should be avoided with a Heat Pump as it is preferable not to lower the temperature.

A5.1 - Creating a new programme


Programmes can be created at 15-minute intervals up to 7 times in 24 hours. For example, the following programme could be created for a Monday:





A5.2 - Copying existing programmes


The first programme, which will be suggested by default, will be the programme from the day before. The dial enables you to access other programmes (other days or pre-recorded).

For example, for a Wednesday:






The screen will revert to the day being programmed, i.e. here it would be Wednesday

- Press  key to confirm and quit programming heating periods.


A5.3 - Changing a programme

The first programme, which will be suggested by default, will be the programme from the day before. The dial enables you to access other programmes (other days or pre-recorded).

For example, for a Monday:



A5.4 - View programme



0945 - 1830
FROST PT.



1830 - 2400
ECO



Press dial to quit viewing
programming for given day.

A6 - Heating circuit water treatment

A6.1 - Preparing the hydraulic circuit (rinsing)

Before installing the HRC⁷⁰ Pilot and HRC⁷⁰ Heat Pump, the installation must be rinsed with a suitable product.

This helps to eliminate all traces of soldering waste, grout, grease, sludge, metallic particles etc. in radiators, underfloor heating etc.

This prevents any of the abovementioned waste getting into the HRC⁷⁰ Heat Pump heat exchanger or blocking the filter which is fitted on the incoming water inlet.

A6.2 - Water for filling

Several different types of material are used to make a heating circuit. Instances of corrosion may occur through galvanic coupling in new and old installations alike.

The water circuit must only be filled using untreated (unsoftened) water from the drinking water circuit. **If water from any other source (e.g. a well or a drill-hole) is used, the warranty is rendered null and void.**

A6.3 - Heating circuit treatment



Central heating installations **MUST BE CLEANED** to eliminate debris (copper, fibres, soldering waste) which can come from setting up the installation or from chemical reactions between metals.

Furthermore, it is important to PROTECT CENTRAL HEATING INSTALLATIONS FROM RISKS OF CORROSION, LIMESCALE AND MICROBIOLOGICAL DEVELOPMENT by using a corrosion inhibitor which is suitable for all types of installations (steel radiators, cast iron, PEX underfloor heating).

PRODUCTS USED FOR HEATING WATER TREATMENT MUST BE APPROVED BY YOUR LOCAL OR NATIONAL PUBLIC HYGIENE AND HEALTH AUTHORITY.

We would recommend the use of SENTINEL products for preventative and curative heating water circuit treatment.

- Fitting the appliance onto new installations (under 6 months)
 - Clean the installation with an all-purpose cleaning product to eliminate installation debris (copper, fibres, soldering waste), for example SENTINEL X300 or SENTINEL X800
 - Rinse the installation thoroughly until the water is clear and completely free of impurities.
 - Protect the installation from corrosion with an inhibitor (for example SENTINEL X100), or from corrosion and frost with an inhibitor and antifreeze agent (for example SENTINEL X500 or SENTINEL R600).
- Fitting the appliance onto existing installations
 - De-sludge the installation with a product for eliminating sludge from the installation (for example SENTINEL X400 or SENTINEL X800).
 - Rinse the installation thoroughly until the water is clear and completely free of impurities.
 - Protect the installation from corrosion with an inhibitor (for example SENTINEL X100), or from corrosion and frost with an inhibitor and antifreeze agent (for example SENTINEL X500 or SENTINEL R600).

The corrosion inhibitor:

- limits limescale formation
- prevents "pinhole" corrosion
- prevents sludge accumulation and the spread of bacteria in new installations (algae in low-temperature circuits)
- prevents hydrogen formation
- eliminates noise from generators

Treatment products from other manufacturers may be used if they guarantee suitability to all the materials used in the installation and they offer effective corrosion resistance.

A6.4 - Frost protection

In cases where the HRC⁷⁰ Heat Pump cannot run (outdoor temperature outside the operating range) if a back-up source is authorised to run (boiler or electrical) it will automatically be protected from frost and ice because the circulator pump will run and extract heat from the heating circuit, which has its temperature maintained either by the HRC⁷⁰ Pilot electrical back-up or by boiler back-up.

However, in case of installation without a back-up source or the Heat Pump or Pilot being switched off during the winter period (e.g. stopping accidentally, use in a second home etc...), it will be necessary to provide additional protection against frost and ice so that you do not need to drain the Heat Pump's hydraulic circuit which is situated outside the building.

Monopropylene glycol should be used as an anti-freeze agent with an added corrosion inhibitor.



Do not use mono-ethylene glycol (toxic product)

Choose the % of glycol according to the minimum outside temperature to protect the water circuit from ice (it should not be less than 25%):

Outdoor temperature (°C)	-10	-15	-20	-25
% of glycol needed	25	30	35	40



When using a pure product that needs to be diluted with water, mix the water, anti-freeze and inhibitor together outside before putting it into the installation.



RENDERING THE WARRANTY NULL & VOID

Any deterioration in the condition of the appliances which is due to unsuitable quality of filling water and / or corrosion in the absence of treatment products as described above and / or improper degassing of the installation will result in the warranty being rendered null and void.



• Regularly check the Ph levels and % of glycol in the installation

• Never top up glycol in your installation without measuring the Ph to check that the drop in the glycol % is not due to deterioration in the glycol.

• When the Ph is acidic (<7) replace all of the glycol after having drained and rinsed the installation beforehand.

A7 - Performance tables

A7.1 - HRC⁷⁰ Heat Pump, 17kW

Temperature Temperature		Modulating thermal heating capacity (kW)		Electrical power consumption (kW)		COP
Air	Water	Max.	min.	Max.	min.	
15°C	35°C	19.8	8.9	4	1.6	4.9
15°C	45°C	18.9	8.5	4.9	2	3.9
15°C	55°C	18.4	8	5.8	2.4	3.2
15°C	70°C	16.6	7.2	7	2.9	2.4
7°C	35°C	16.7	7.2	4	1.7	4.3
7°C	45°C	16.5	6.5	4.8	1.8	3.6
7°C	55°C	16	6.1	5.6	2.1	3
7°C	70°C	14.6	5.7	6.7	2.4	2.3
0°C	35°C	14.1	6	3.9	1.6	3.3
0°C	45°C	13.9	5.8	4.6	1.9	2.7
0°C	55°C	13.2	5.5	5.3	2.1	2.4
0°C	70°C	12.2	5	6.3	2.6	2.1
-7°C	35°C	12.1	5	3.8	1.5	3
-7°C	45°C	11.6	4.8	4.4	1.8	2.5
-7°C	55°C	11.1	4.6	5	2	2.2
-7°C	70°C	10.5	4.3	6.1	2.5	1.7
-15°C	35°C	9.7	4.1	3.5	1.4	2.7
-15°C	45°C	9.4	3.9	4.1	1.7	2.3
-15°C	55°C	9.2	3.8	4.7	1.9	1.9
-15°C	70°C *	8.9	3.7	5.8	2.4	1.5
-20°C	35°C	8.3	3.5	3.4	1.4	2.5
-20°C	45°C	8.1	3.4	3.9	1.6	2.1
-20°C	55°C	8	3.3	4.6	1.9	1.8
-20°C	70°C *	7.9	3.3	5.6	2.3	1.4

* When outdoor air temperatures are below -10°C, operating at 70°C is intermittent

A7.2 - HRC⁷⁰ Heat Pump, 20kW

Temperature Temperature		Modulating thermal heating capacity (kW)		Electrical power consumption (kW)		COP
Air	Water	Max.	min.	Max.	min.	
15°C	35°C	23.2	13.1	4.8	2.4	4.8
15°C	45°C	22.2	12.5	5.8	3	3.8
15°C	55°C	21.6	11.9	6.9	3.5	3.1
15°C	70°C	19.5	10.7	8.3	4.3	2.3
7°C	35°C	19.6	10.4	4.8	2.8	3.7
7°C	45°C	19.3	10.4	5.7	3.0	3.4
7°C	55°C	18.8	9.9	6.6	3.4	2.9
7°C	70°C	17.6	9.3	8	3.5	2.7
0°C	35°C	16.5	8.9	4.6	2.4	3.2
0°C	45°C	16.3	8.5	5.4	2.8	2.7
0°C	55°C	15.9	8.1	6.3	3.2	2.4
0°C	70°C	14.7	7.5	7.6	3.8	2
-7°C	35°C	14.2	7.4	4.5	2.3	3
-7°C	45°C	14	7.1	5.2	2.7	2.5
-7°C	55°C	13.5	6.8	6	3	2.2
-7°C	70°C	12.7	6.4	7.3	3.7	1.7
-15°C	35°C	11.8	6	4.2	2.2	2.8
-15°C	45°C	11.4	5.8	4.9	2.5	2.3
-15°C	55°C	11.1	5.6	5.6	2.9	2
-15°C	70°C *	10.8	5.5	7	3.5	1.5
-20°C	35°C	10	5.1	4	2.1	2.5
-20°C	45°C	9.8	5	4.7	2.4	2.1
-20°C	55°C	9.7	4.9	5.4	2.8	1.8
-20°C	70°C *	9.5	4.8	6.7	3.4	1.4

* When outdoor air temperatures are below -10°C, operating at 70°C is intermittent



A7.3 - HRC⁷⁰ Heat Pump, 25kW

Temperature Temperature		Modulating thermal heating capacity (kW)		Electrical power consumption (kW)		COP
Air	Water	Max.	min.	Max.	min.	
15°C	35°C	28.3	13.1	5.8	2.3	4.9
15°C	45°C	27.1	12.5	7.1	2.9	3.8
15°C	55°C	26.4	11.9	8.3	3.4	3.2
15°C	70°C	23.8	10.7	10.1	4.2	2.4
7°C	35°C	24	10.3	5.7	2.5	4.1
7°C	45°C	23.6	10.1	6.9	2.9	3.6
7°C	55°C	23	9.8	8	3.3	3
7°C	70°C	21.5	9.3	9.8	3.9	2.4
0°C	35°C	20.1	8.9	5.6	2.3	3.3
0°C	45°C	19.9	8.5	6.6	2.7	2.9
0°C	55°C	19.5	8.1	7.6	3.1	2.5
0°C	70°C	18	7.5	9.2	3.8	2.1
-7°C	35°C	17.3	7.4	5.4	2.2	3
-7°C	45°C	17.1	7.1	6.3	2.6	2.7
-7°C	55°C	16.4	6.8	7.2	2.9	2.3
-7°C	70°C	15.5	6.4	8.8	3.6	1.8
-15°C	35°C	14.4	6	5.1	2.1	2.8
-15°C	45°C	13.9	5.8	5.9	2.4	2.4
-15°C	55°C	13.5	5.6	6.8	2.8	2
-15°C	70°C *	13.2	5.5	8.5	3.4	1.6
-20°C	35°C	12.2	5.1	4.8	2	2.5
-20°C	45°C	12	5	5.6	2.3	2.1
-20°C	55°C	11.8	4.9	6.6	2.7	1.8
-20°C	70°C *	11.7	4.8	8.1	3.3	1.4

* When outdoor air temperatures are below -10°C, operating at 70°C is intermittent

Hydraulic schematic diagram -1 RADIATOR CIRCUIT- -swimming pool possible-


HPCP	= Heat Pump circulator pump	FRM SP	= Swimming pool flow rate monitor
C1CP	= heating circuit 1 circulator pump	S pool	= Swimming pool sensor (optional, included in swimming pool kit)
FRM	= Heat Pump flow rate monitor	C pool	= swimming pool circulator pump
SV	= 3-bar safety valve	3WV	= 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
P	= air valve	BCV	= boiler check valve
PTS	= HRC ⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)		
SA	= safety aquastat with manual reset, 110 °C		
WP	= water pressure sensor		
SRV	= sludge removal valve		
FV	= Heat Pump circuit filter valve		
V	= stop valves		
CV	= check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).		
EV	= expansion vessel		
BPD	= backflow prevention device		
F	= flexible hose for Heat Pump connection		
MAV	= manual air valve		
HPSV	= Heat Pump safety valve, set to 2.5 bar		
HPIWS	= Heat Pump incoming water temperature sensor		
HPOWS	= Heat Pump outgoing water temperature sensor		
EBCP	= existing boiler circulator pump		
EVE	= expansion vessel for existing installation		
BSV	= safety valve for existing boiler		
OTS	= Heat Pump HRC ⁷⁰ Pilot outdoor temperature sensor		
TC1	= heating circuit 1 temperature sensor		
or RTS1	= room temperature sensor with display for heating circuit 1(optional)		




Hydraulic schematic diagram-1 UNDERFLOOR HEATING CIRCUIT- - pool possible-

HPCP	= Heat Pump circulator pump
C1CP	= heating circuit 1 circulator pump
FRM	= Heat Pump flow rate monitor
SV	= 3-bar safety valve
P	= air valve
PTS	= HRC ⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)
SA	= safety aquastat with manual reset, 110 °C
WP	= water pressure sensor
SRV	= sludge removal valve
FV	= Heat Pump circuit filter valve
V	= stop valves
CV	= check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).
EV	= expansion vessel
BPD	= backflow prevention device
F	= flexible hose for Heat Pump connection
MAV	= manual air valve
HPSV	= Heat Pump safety valve, set to 2.5 bar
HPIWS	= Heat Pump incoming water temperature sensor
HPOWS	= Heat Pump outgoing water temperature sensor
EBCP	= existing boiler circulator pump
EVE	= expansion vessel for existing installation
BSV	= safety valve for existing boiler
OTS	= Heat Pump HRC ⁷⁰ Pilot outdoor temperature sensor
TC1	= heating circuit 1 room thermostat
or RTS1	= room temperature sensor with display for heating circuit 1 (optional)
UTL1	= temperature-limiting safety device when underfloor heating is circuit 1 (optional)
FRM SP	= Swimming pool flow rate monitor
S pool	= Swimming pool sensor (optional, included in swimming pool kit)

C pool	= swimming pool circulator pump
3WV	= 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
BCV	= boiler check valve



HRC⁷⁰ PILOT





Hydraulic schematic diagram -2 RADIATOR CIRCUITS- -pool possible-

HPCP = Heat Pump circulator pump
 C1CP = heating circuit 1 circulator pump
 C2CP = heating circuit 2 circulator pump
 FRM = Heat Pump flow rate monitor
 SV = 3-bar safety valve
 P = air valve
 PTS = HRC⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)
 SA = safety aquastat with manual reset, 110 °C
 WP = water pressure sensor
 SRV = sludge removal valve
 FV = Heat Pump circuit filter valve
 V = stop valves
 CV = check valve (to be used if HRC⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).

EV = expansion vessel
 BPD = backflow prevention device
 F = flexible hose for Heat Pump connection
 MAV = manual air valve
 HPSV = Heat Pump safety valve, set to 2.5 bar
 HPIWS = Heat Pump incoming water temperature sensor
 HPOWS = Heat Pump outgoing water temperature sensor
 EBCP = existing boiler circulator pump
 EVE = expansion vessel for existing installation
 BSV = safety valve for existing boiler
 OTS = Heat Pump HRC⁷⁰ Pilot outdoor temperature sensor
 TC1 = heating circuit 1 room thermostat
 or RTS1 = room temperature sensor with display for heating circuit 1(optional)
 TC2 = heating circuit 2 room thermostat

or RTS2 = room temperature sensor for heating circuit 2 (optional)
 UTL1 = temperature-limiting safety device when underfloor heating is circuit 1(optional)
 UTL2 = temperature-limiting safety device when underfloor heating is circuit 2 (optional)
 FRM SP = Swimming pool flow rate monitor
 S pool = Swimming pool sensor (optional, included in swimming pool kit)
 C pool = swimming pool circulator pump
 3WV = 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
 BCV = boiler check valve




Hydraulic schematic diagram -2 UNDERFLOOR CIRCUITS - -pool possible-

HPCP = Heat Pump circulator pump
 C1CP = heating circuit 1 circulator pump
 C2CP = heating circuit 2 circulator pump
 FRM = Heat Pump flow rate monitor
 SV = 3-bar safety valve
 P = air valve
 PTS = HRC⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)
 SA = safety aquastat with manual reset, 110 °C
 WP = water pressure sensor
 SRV = sludge removal valve
 FV = Heat Pump circuit filter valve
 V = stop valves
 CV = check valve (to be used if HRC⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).


EV = expansion vessel
 BPD = backflow prevention device
 F = flexible hose for Heat Pump connection
 MAV = manual air valve
 HPSV = Heat Pump safety valve, set to 2.5 bar
 HPIWS = Heat Pump incoming water temperature sensor
 HPOWS = Heat Pump outgoing water temperature sensor
 EBCP = existing boiler circulator pump
 EVE = expansion vessel for existing installation
 BSV = safety valve for existing boiler
 OTS = Heat Pump HRC⁷⁰ Pilot outdoor temperature sensor
 TC1 = heating circuit 1 room thermostat
 or RTS1 = room temperature sensor with display for heating circuit 1 (optional)
 TC2 = heating circuit 2 room thermostat
 or RTS2 = room temperature sensor for heating circuit

2 (optional)
 UTL1 = temperature-limiting safety device when underfloor heating is circuit 1 (optional)
 UTL2 = temperature-limiting safety device when underfloor heating is circuit 2 (optional)
 FRM SP = Swimming pool flow rate monitor
 S pool = Swimming pool sensor (optional, included in swimming pool kit)
 C pool = swimming pool circulator pump
 3WV = 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
 BCV = boiler check valve



PILOT HRC



70



Hydraulic schematic diagram -1 RADIATOR CIRCUIT/ + DHW- -pool possible-

HPCP	= Heat Pump circulator pump
C1CP	= heating circuit 1 circulator pump
FRM	= Heat Pump flow rate monitor
SV	= 3-bar safety valve
P	= air valve
PTS	= HRC ⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)
SA	= safety aquastat with manual reset, 110 °C
WP	= water pressure sensor
SRV	= sludge removal valve
FV	= Heat Pump circuit filter valve
V	= stop valves
CV	= check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).
EV	= expansion vessel
BPD	= backflow prevention device
F	= flexible hose for Heat Pump connection
MAV	= manual air valve
HPSV	= Heat Pump safety valve, set to 2.5 bar
HPIWS	= Heat Pump incoming water temperature sensor
HPOWS	= Heat Pump outgoing water temperature sensor
EBCP	= existing boiler circulator pump
EVE	= expansion vessel for existing installation
BSV	= safety valve for existing boiler
OTS	= Heat Pump HRC ⁷⁰ Pilot outdoor temperature sensor
TC1	= heating circuit 1 room thermostat
or RTS1	= room temperature sensor with display for heating circuit 1(optional)
or RTS2	= room temperature sensor for heating circuit 2 (optional)
AQDHW	= Heating circuit 2 aquastat
DHWS	= Heating circuit 2 DHW temperature sensor (optional)
FRM SP	= Swimming pool flow rate monitor
S pool	= Swimming pool sensor (optional, included in swimming pool kit)



C pool	= swimming pool circulator pump
3WV	= 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
BCV	= boiler check valve
DHW	= DHW tank with >40kW heat exchanger



Hydraulic schematic diagram -1 RADIATOR CIRCUIT + POOL-

HPCP	=	Heat Pump circulator pump
C1CP	=	heating circuit 1 circulator pump
C2CP	=	heating circuit 2 circulator pump
FRM	=	Heat Pump flow rate monitor
SV	=	3-bar safety valve
P	=	air valve
PTS	=	HRC ⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)
SA	=	safety aquastat with manual reset, 110 °C
WP	=	water pressure sensor
SRV	=	sludge removal valve
FV	=	Heat Pump circuit filter valve
V	=	stop valves
CV	=	check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).
EV	=	expansion vessel
BPD	=	backflow prevention device
F	=	flexible hose for Heat Pump connection
MAV	=	manual air valve
HPSV	=	Heat Pump safety valve, set to 2.5 bar
HPIWS	=	Heat Pump incoming water temperature sensor
HPOWS	=	Heat Pump outgoing water temperature sensor
EBCP	=	existing boiler circulator pump
EVE	=	expansion vessel for existing installation
BSV	=	safety valve for existing boiler
OTS	=	Heat Pump HRC ⁷⁰ Pilot outdoor temperature sensor
TC2	=	heating circuit 2 room thermostat
or RTS2	=	room temperature sensor for heating circuit 2 (optional)
FRM SP	=	Swimming pool flow rate monitor
S pool	=	Swimming pool sensor (optional, included in swimming pool kit)



C pool	=	swimming pool circulator pump
3WV	=	3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
BCV	=	boiler check valve



Hydraulic schematic diagram -1 POOL CIRCUIT + DHW -


HPCP	= Heat Pump circulator pump
C1CP	= heating circuit 1 circulator pump
C2CP	= heating circuit 2 circulator pump (optional)
FRM	= Heat Pump flow rate monitor
SV	= 3-bar safety valve
P	= air valve
PTS	= HRC ⁷⁰ Pilot temperature sensor (or outgoing water (OW) temperature sensor)
SA	= safety aquastat with manual reset, 110 °C
WP	= water pressure sensor
SRV	= sludge removal valve
FV	= Heat Pump circuit filter valve
V	= stop valves
CV	= check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the Heat Pump to avoid a thermosiphon effect).
EV	= expansion vessel
BPD	= backflow prevention device
F	= flexible hose for Heat Pump connection
MAV	= manual air valve
HPSV	= Heat Pump safety valve, set to 2.5 bar
HPIWS	= Heat Pump incoming water temperature sensor
HPOWS	= Heat Pump outgoing water temperature sensor
EBCP	= existing boiler circulator pump
EVE	= expansion vessel for existing installation
BSV	= safety valve for existing boiler
OTS	= Heat Pump HRC ⁷⁰ Pilot outdoor temperature sensor
AQ DHW	= Heating circuit 2 DHW aquastat
or DHWS2	= Heating circuit 2 DHW temperature sensor(optional)
FRM SP	= Swimming pool flow rate monitor
S pool	= Swimming pool sensor (optional, included in swimming pool kit)
C pool	= swimming pool circulator pump

3VV	= 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
DHW	= DHW tank with >40kW heat exchanger



Hydraulic schematic diagram -1 DIRECT CIRCUIT and 1 MIXED CIRCUIT- with optional 2nd circuit at lower temperature (Ref.751014) -pool possible-


HPCP	=	heat pump circulator pump
C1CP	=	heating circuit 1 circulator pump
FRM	=	heat pump circuit flow rate monitor
S	=	3 bar safety valve
P	=	air valve
PTS	=	HRC ⁷⁰ Pilot temperature sensor (or OWTS)
SAQ	=	safety aquastat with manual reset at 110°C
WP	=	water pressure sensor
SRV	=	sludge removal valve
FV	=	heat pump circuit filter valve
V	=	stop valves
CV	=	check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the heat pump to avoid a thermosiphon effect)
EV	=	expansion vessel
BPD	=	backflow prevention device
F	=	flexible hose for heat pump connection
MAV	=	manual air valve
HPSV	=	heat pump safety valve set to 2.5 bar
HPIWS	=	heat pump incoming water temperature sensor
HPOWS	=	heat pump outgoing water temperature sensor
EBCP	=	existing boiler circulator pump
EVE	=	expansion vessel for existing installation
BSV	=	existing boiler safety valve
OS	=	Heat pump HRC ⁷⁰ Pilot outdoor temperature sensor
RTC1	=	Heating circuit 1 room thermostat or temperature sensor (optional)
or RTS1	=	temperature-limiting safety device if circuit 1 is underfloor heating circuit (optional)
UTL 1	=	temperature-limiting safety device if circuit 1 is underfloor heating circuit (optional)
FRM SP	=	swimming pool flow rate monitor
S pool	=	swimming pool temperature sensor (included in swimming pool kit)
C pool	=	pool circuit circulator pump
3WV	=	3-way valve for radiator circuit (winter) or pool circuit (summer)



BCV	=	boiler check valve
RT or RTS	=	room thermostat or room temperature sensor on 2 nd circuit at a lower temperature 'Thorix Evolution'

On the Pilot: • The 2nd circuit (RADIATOR C-2) or (UNDERFLOOR C-2), which must be the same kind as the first circuit connected to the Pilot, must be activated.


• Activate the room thermostat input (THERMOSTAT A-2) on the second circuit in order to monitor heat pump operation using the on / off alert output on the Thorix Evolution (set *P219 = 1* on the Thorix Evolution)



Hydraulic schematic diagram -2 DIRECT CIRCUITS and 3rd MIXED CIRCUIT - with an optional 2nd circuit at a lower temperature (Ref.751014) and optional 2-way motorised valve for 1st direct circuit (Ref. 740022) -pool possible-

HPCP	= heat pump circulator pump
C1CP	= heating circuit 1 circulator pump
C2CP	= heating circuit 2 circulator pump (optional)
FRM	= heat pump flow rate monitor
S	= 3 bar safety valve
P	= air valve
PTS	= HRC ⁷⁰ Pilot temperature sensor (or OWTs)
SAQ	= safety aquastat with manual reset at 110°C
WP	= water pressure sensor
SRV	= sludge removal valve
FV	= heat pump circuit filter valve
V	= stop valves
CV	= check valve (to be used if HRC ⁷⁰ Pilot is installed on a lower level than the heat pump to avoid a thermosiphon effect)
EV	= expansion vessel
BPD	= backflow prevention device
F	= flexible hose for heat pump connection
MAV	= manual air valve
HPSV	= heat pump safety valve set to 2.5 bar
HPIWS	= heat pump incoming water temperature sensor
HPOWS	= heat pump outgoing water temperature sensor
EBCP	= existing boiler circulator pump
EVE	= expansion vessel for existing installation
BSV	= existing boiler safety valve
OS	= Heat pump HRC ⁷⁰ Pilot outdoor temperature sensor
RT1	= Heating circuit 2 room thermostat (optional)
UTL 1	= temperature-limiting safety device if circuit 1 is underfloor heating circuit (optional)
FRM SP	= swimming pool flow rate monitor
S pool	= swimming pool temperature sensor (included in swimming pool kit)
C pool	= pool circuit circulator pump
3WV	= 3-way valve for radiator circuit (winter) or pool circuit (summer)


BCV	= boiler check valve
RT or RTS	= room thermostat or room temperature sensor on 2 nd circuit at a lower temperature 'Thorix Evolution'





On the P :


- The 2nd circuit (RADIATOR C-2) or (UNDERFLOOR C-2), which must be the same kind as the first circuit connected to the Pilot, must be activated.

- Activate the room thermostat input (THERMOSTAT A-2) on the second circuit in order to monitor heat pump operation using the on / off alert output on the Thorix Evolution (set *P219 = 1* on the Thorix Evolution)






HRC⁷⁰ Heat Pump - 17kW single phase- internal wiring diagram








- TsPAC : Outgoing water temperature sensor
- TePAC : Incoming water temperature sensor
- Tdégiv : De-icing temperature sensor
- Tair : Incoming air temperature sensor
- Tcomp1 : Compressor 1 temperature sensor
- Tcomp2 : Compressor 2 temperature sensor
- HP1 : Compressor 1 high pressure switch
- HP2 : Compressor 2 high pressure switch
- BP : Low pressure switch
- CP1 : Compressor 1 start-up command
- CP2 : Compressor 2 start-up command
- VEM : De-icing solenoid valve cycle inversion command
- CH1 : Compressor 1 RK1 heater cable
- CH2 : Compressor 2 RK2 heater cable
- CC : External heater cable
- VT : Command speed 3 -fan-
- V2 : Command speed 2 -fan-
- V1 : Command speed 1 -fan-
- F : 5x20 4A fuse
- CV2 : 18µF capacitor speed 2 -fan-
- CV1 : 12µF capacitor speed 1 -fan-
- C1 : Compressor 1 45µF capacitor
- C2 : Compressor 2 45µF capacitor
- K1 : Compressor 1 thermal protection device
- K2 : Compressor 2 thermal protection device
- VENT : Fan
- DC1 : Compressor1 starter
- DC2 : Compressor 2 starter
- RK1 : Compressor 1 crank case heater
- RK2 : Compressor 2 crank case heater
- EV : De-icing solenoid valve


HRC⁷⁰ Heat Pump- 17kW three phase- internal wiring diagram








HRC⁷⁰ Heat Pump- 20kW three phase- internal wiring diagram







- TsPAC : Outgoing water temperature sensor
- TePAC : Incoming water temperature sensor
- Tdegiv : De-icing temperture sensor
- Tair : Incoming air temperature sensor
- Tcomp1 : Compressor 1 temperature sensor
- Tcomp2 : Compressor 2 temperature sensor
- HP1 : Compressor 1 high pressure switch
- HP2 : Compressor 2 high pressure switch
- BP : Low pressure switch
- CP1 : Compressor 1 start-up command
- CP2 : Compressor 2 start-up command
- VEM : De-icing solenoid valve cycle inversion command
- CH1 : Compressor 1 RK1 heater cable
- CH2 : Compressor 2 RK2 heater cable
- CC : External heater cable
- VT : Command speed 3 -fan-
- V2 : Command speed 2 -fan-
- V1 : Command speed 1 -fan-
- F : 5x20 4A fuse
- CV2 : 18µF capacitor speed 2 -fan-
- CV1 : 12µF capacitor speed 1 -fan-
- K1 : Compressor 1 thermal protection device
- K2 : Compressor 2 thermal protection device
- VENT : Fan
- RCP : Phase monitor
- KMC1 : Compressor 1 contactor
- KMC2 : Compressor 2 contactor
- RK1 : Compressor 1 crank case heater
- RK2 : Compressor 2 crank case heater
- EV : De-icing solenoid valve


HRC⁷⁰ Heat Pump- 25kW three phase - internal wiring diagram





HRC⁷⁰ Pilot electrical schematic diagram





Please see following pages for key

Key:• HRC⁷⁰ Pilot schematic electrical diagram

• HRC⁷⁰ Pilot internal wiring diagram

L1 + L2 + L3 + N + Ground = 400 V three phase power supply for HRC⁷⁰ Pilot (as wired at factory) (for a 230V single phase power supply, see § Connecting the HRC⁷⁰ Pilot to the power supply)

HPCP= Heat Pump circuit circulator pump

C1CP.....= Heating circuit 1 circulator pump

C2CP.....= Heating circuit 2 circulator pump (optional)

HPFM= Heat Pump circuit flow rate monitor

SP= HRC⁷⁰ Pilot temperature sensor (TSeau input / electronics board)

SAQ.....= HRC⁷⁰ Pilot safety aquastat with manual reset 110°C

WPS.....= HRC⁷⁰ Pilot water pressure sensor

OS.....= HRC⁷⁰ Pilot Heat Pump outdoor temperature sensor (Ext. input /electronics board)

TC1= Heating circuit 1 room thermostat (Amb1 input / electronics board) (optional)

or TSC1= Heating circuit 1 room temperature sensor with display (Amb1 input / electronics board) (optional)

TC2= Heating circuit 2 room thermostat (Amb2 input / electronics board) (optional)

ou TSC2= Heating circuit 2 temperature sensor (Amb2 input / electronics board) (optional)

AQ DHW.....= Circuit 2 domestic water aquastat (Amb2 input / electronics board)

or SECS= Heating circuit 2 domestic water temperature sensor (Amb2 input / electronics board) (optional)

Del= Load shedding input

HP/HC= Peak / off peak time input

App1= 230 V output electrical back-up command, 1st stage

App2= 230 V output electrical back-up command, 2nd stage

App3= 230 V output electrical back-up command, 3rd stage

Chaud.= On / off command for existing boiler

BUS= Link between Heat Pump / HRC⁷⁰ Pilot with sheathed 2-core cable (10m long supplied, 20m available to order -Ref.751005)

USB= Memory stick input for reading recorded data

F1= 4A protection fuse for electronics board

Alim= Electronics board power supply 230 V + ground

LTP 1 / UTL 1= temperature-limiting safety device for underfloor heating as circuit 1 (optional)

LTP 2 / UTL 2= temperature-limiting safety device for underfloor heating as circuit 2 (optional)

K1 ; K2 ; K3= Power contactors stages 1 to 3

T= Electrical back-up from 2000 W electric immersion heater


Optional swimming pool kit:

IP= Switch for heating (winter) / pool (summer)

RP1 and RP2= Swimming pool relay

SFM= Swimming pool flow rate monitor
S pool= Swimming pool temperature sensor
VP= 3-way valve for radiator circuit (winter) or swimming pool circuit (summer)
F2= 4A swimming pool circuit protection fuse
C pool.....= Swimming pool circuit circulator pump

HRC⁷⁰ Pilot internal wiring diagram



A8 - Electricity provider information form

This form is to give to your electricity provider for any preliminary study undertaken for installing a HRC Heat Pump, in case of insufficient supply from the power grid.

This table recapitulates both information on electrical installation and HRC Heat Pump technical data.

You can find the technical data in the table in the § "Connecting the HRC Heat Pump to the power supply" section.

If necessary, your electricity provider can reinforce the power lines after the installation study.

Name of client			
Address			
Client reference number on electricity bill			
Name and address of installer			
Connections	Single phase <input type="checkbox"/> Three phase <input type="checkbox"/> *		
Circuit breaker	Setting: _____ A		
Heat Pump (HP)			
Type of pump	Single phase <input type="checkbox"/> Three phase <input type="checkbox"/> *		
Model, make and reference number	_____		
Type of compressor (<u>without back-up heating</u>)	Single phase <input type="checkbox"/> Three phase <input type="checkbox"/> *		
Nominal heating capacity of Heat Pump without elements for heating back-up (kVA)	_____ (kVA) *		
Or	Or		
HP nominal current without elements for heating back-up (A)	_____ (A) *		
HP start-up current (A)	_____ (A) *		
HP impedance (Z_{max}) declared by manufacturer	_____ (Ω)		
HP power regulating mode	Fixed speed <input type="checkbox"/>	Variable speed <input type="checkbox"/>	
Is there a start-up support system in place for fixed-speed systems?	Yes <input type="checkbox"/> *	No <input type="checkbox"/> *	-
Elements for heating back-up	Single phase <input type="checkbox"/>		Three phase <input type="checkbox"/> *
	_____ (kVA)		
* mandatory fields			

NOTES:



Industrial and development site

Rue de la République
CS 40029
80210 Feuquières-en-Vimeu
France

Spare parts

Tel. : 03 22 61 21 21
Fax : 03 22 61 33 35
E-mail : pieces@auer.fr

After-sales and technical service

E-mail : sav@auer.fr